SERVICE

2502B AND 2502BM TELEPHONE SETS

1. GENERAL

1.01 Reissued to:

- Add D4BU, D6AM, D6AL, or D6AP mounting cord and 153-adapter, 625-type, or 74D connecting block, Fig. 2
- Change C4B ringer to H1B ringer, Fig. 2
- Show 2502B telephone set MD, Fig. 1.

TABLE A

POLARITY GUARD CONNECTIONS [819040528 (P-90D052) GUARD ASSEMBLY]


LEAD	COLOR	FROM REMOVE	CONNECT TO	
			POLARITY	NET.
Dial	BK	RR	Т	
Line Switch	W	С	8	
Polarity Guard	W			C
	G			RR

Note: For use when specified by local instructions for end-to-end signaling installations.

NOTICE

Not for use or disclosure outside the Bell System except under written agreement

Printed in U.S.A.




NOTES:

- 1. ON SETS EQUIPPED WITH A 425G NETWORK, THE LEADS SHOWN CONNECTED TO THE S AND T TERMINALS SHOULD BE CONNECTED TO TERMINALS 3 AND 4 RESPECTIVELY ON THE TERMINAL STRIP.
- 2. SETS ARE FACTORY WIRED FOR BRIDGED RINGING SERVICE. CONNECTIONS FOR C48 RINGER SHOWN, IF C4A RINGER IS USED WIRE AS FOLLOWS: (BK) TO 2 OF TERM. STRIP (S-R) TO A OF NETWORK (S) TO K OF NETWORK (R) TO I OF TERM. STRIP
- REMOVE (S) STRAP FROM A OF NETWORK TO TERMINAL I. 3. TO SILENCE RINGER FOR ALL CLASSES OF SERVICE REFER TO APPROPRIATE SECTION IN DIVISION 501.
- 4. LINE SWITCH SEQUENCE, HANDSET REMOVED: bc MAKES de MAKES

 - fg BREAKS

Fig. 1—2502B (MD) Telephone Set, Connections (Factory-Wired)



NOTES:

- SETS ARE FACTORY WIRED FOR BRIDGED RINGING SERVICE, CONNECTIONS FOR C48 RINGER SHOWN. IF C4A RINGER IS USED WIRE AS FOLLOWS:
 - (BK) TO 2 OF TERM, STRIP (S-R) TO A OF NETWORK
 (S) TO K OF NETWORK (R) TO 1 OF TERM, STRIP
 REMOVE (S) STRAP FROM A OF NETWORK TO TERMINAL 1.
- 2. TO SI ENCE RINGER PERMANENTLY, REMOVE (BK) RINGER LEAD FROM 2
- OF TERMINAL STRIP, INSULATE AND STORE.

 3. LINE SHITCH SEQUENCE, HANDSET REMOVED:

bc - MAKES de - MAKES fg - BREAKS

4. HADU CORD MUST BE ORDERED SEPARATELY.

Fig. 2-\$2502BM Telephone Set, Connections\$