# SERVICE

## 663-TYPE TELEPHONE SETS

#### 1. GENERAL

1.01 These sets are supplied factory wired with a 242-type amplifier to provide for headset operation. A 52- or 53-type headset must be ordered separately. For ordering and installation information refer to the appropriate Reference section in Division 502.

1.02 Connection information was formerly found in Section 502-660-403 which will be canceled.




Fig. 1—242A Amplifier Connections — 663A1
Telephone Set

### TABLE A

### AMPLIFIER CONNECTIONS — 663A1 TELEPHONE SET

LEAD	242A AMPLIFIER	242B AMPLIFIER*		
V-G	R	2		
G-V	2	Т		
O-V	1	1		
R	2	2		
S	R	T		
ВК	2	2		

\* Place P-29E318 strap or equivalent between R and T terminals of amplifier.

TABLE B

LINE AND RINGER CONNECTIONS — 663A1 TELEPHONE SET

WIRE OR LEAD			INDIV OR BRIDGED	RING PARTY	TIP PARTY		
					NO IDENT	IDENT GROUND	
					GROUND	1000Ω	2650Ω
Line Wire	Tip	Block	1,,,,,,	1	1	1	of T 1 10.
	Ring		2	2	2	2	2
	Grd A1		5*	5	5	5	5
	A	Connecting 3	4	4	4	4	4
Mounting Cord	G		1	1	1	1	1
	R		2	2	2	2	2
	Y		4	4	4	4	4
	BK		5	5	5	5	5
Mounting Cord in Set	G	TB1	2	2	2	2	2
	R		C†	C†	C†	F†	F÷
	Y		1	1	1	1	1
	BK		3	3	3	3	3
Ringer Leads	R	TB2	7	7	7	7	7
	BK		8	8	8	8	8
	S		9	9	9	9	9
	S-R		10	10	10	9	9
Ringer Straps	R	Net.	C	С	2‡	K	3‡
	BK		2‡	3 <sup>†</sup>	3‡	3‡	K
	S		K	K	K	В	В
	S-R		A	A	A	B§	B§
Line Switch	[S-BR] (W)	Net.	G	G	G	G	G
Key Assembly Leads	S-V		F	F	F	С	С

<sup>\*</sup> Ground may be omitted if not required for service. Not required for protection of 41-type dial power supply.

<sup>†</sup> Network terminal.

<sup>‡</sup> TB1.

Flace M1W cord or equivalent from A of network to 2 of TB1.

<sup>( )</sup> Current color code

<sup>[ ]</sup> MD color code




Fig. 2-663A1 Telephone Set, Connections