

SPEAKERPHONE SYSTEM—3-TYPE

2752-TYPE TELEPHONE SETS

CONNECTIONS AND MAINTENANCE

1. GENERAL

1.01 This section provides connections for the 2752-type telephone set when used with a 3-type speakerphone system.

1.02 This section is reissued to:

- Change section reference in read note, 2.02, and 3.02

- Change callout, Fig. 1

2. CONNECTIONS

2.01 The 2752-type telephone set is equipped with loudspeaker, transmitter, and speakerphone ON-OFF and volume controls. No conversion or wiring changes are necessary for speakerphone operation.




Refer to Division 512 for connections if 3-type speakerphone is to be provided in conjunction with 1A home interphone.

2.02 Refer to Division 502 for the 2752-type telephone set connections. ♦

3. MAINTENANCE

3.01 Maintenance of the speakerphone components of these sets (Fig. 1) is limited to checking for loose or broken connections and replacement of defective units.

3.02 Refer to Division 502 for maintenance information for the 2752-type telephone sets. Refer to Division 512 for speakerphone system requirements and maintenance information. ♦



♦ Fig. 1—Speakerphone Components ♦

NOTES:

1. CONNECT FOR BUSY LAMP CONTROLLED BY SPEAKERPHONE CONTROL UNIT ONLY; ADD STRAP TERMINAL 19 TO 21(55B) OR 26 TO 29(55A*).
2. CONNECT SP2 LEAD TO TERMINAL 30 (55B) OR 24(55A) CONTROL UNIT IF REDUCED LOUDSPEAKER VOLUME IS DESIRED.
3. THE 55A CONTROL UNIT MUST BE MODIFIED FOR USE WITH THE TOUCH-TONE® DIAL EQUIPPED SETS. MODIFIED UNITS ARE IDENTIFIED BY AN ASTERISK FOLLOWING THE CODE.
4. INTERCONNECTIONS MAY BE MADE USING AN A25B CONNECTOR CABLE WHEN THE 55-TYPE CONTROL UNIT IS LOCATED AT THE KEY EQUIPMENT.




Fig. 2—2752-Type Telephone Set, Connections To 3-Type Speakerphone System