BELL SYSTEM PRACTICES AT&TCo Standard

7A COMMUNICATION SYSTEM-(COM KEY* 718)

IDENTIFICATION, INSTALLATION, CONNECTION, OPERATION, AND MAINTENANCE

		CONT	ENT	S					P	AGE
1.	GENERAL .									2
2.	DESCRIPTION O	OF APP	ARA	TUS						3
	570-TYPE KSU									3
	CONSOLES									7
		OUNTE	DA	PPA	RA	rus	5			12
	KEY TELEPHON	E UNIT	s							13
	KITS OF PARTS	s .								16
	TELEPHONE SE	TS								17
3.	INSTALLATION									20
	PLANNING			•						20
	ORDERING GU	IDE								21
	INSTALLING	• •								24
	А. 570-Туре	KSU								24
	B. Satellite V	/iring P	Plan		•					25
	C. Satellite Terminal I	Plan Block	Usir	ng (14	A 1	-10		25
	D. Satellite P	lan Usi	ing	Nom	ogr	ap	h			27
	E. Telephone	Sets								27
4.	FEATURES (ID	ENTIFIC	TES	ON,	0	PER	A1	01	N,	32
	BASIC FEATUR	ES								32
	Trademark of AT&	T Comp	anv							

	CONTENTS	PAGE
Α.	Automatic Button Restoration (ABR)	. 32
в.	Common Audible	. 32
c.	Multiline Conferencing	. 35
D.	Pickup, Hold, and Illumination .	. 36
E.	Tone and Voice Signaling	. 36
F.	2-Path Intercom	. 36
OP	TIONAL FEATURES	. 38
A.	CO Ringing	. 38
В.	External Signaling Circuit	. 38
C.	Intercom Preset Conference	. 39
D.	Music-On-Hold	. 43
E.	Ring Transfer	. 44
F.	Paging and Background Music	. 46
G.	Power Failure Ringer	51
н.	Power Failure Transfer	. 51
I.	Privacy	. 51
J.	Privacy Release	52
к.	Recall	54
L.	Speakerphone	55
	3B Speakerphone	55
	4A Speakerphone	55

NOTICE

Not for use or disclosure outside the Bell System except under written agreement

Printed in U.S.A.

SECTION 518-450-100

		CONTENTS PAGE	
	м.	Station Busy Consoles 58	
		Station Busy Console (6A1) With DSS	
		Station Busy Console (6B1) With MW	
		62	
	N.	Multiple Consoles 62	
	0.	Station Restriction 63	
	Ρ.	TOUCH-TONE® Dialing 66	
	Q.	Automatic, DC Signaling, Private Line	
		Circuit 70	
5.	GE	NERAL MAINTENANCE 72	
6.	DET	TAILED MAINTENANCE	

1. GENERAL

- 1.01 This section contains information for the 7A Communication System.
- 1.02 This section is reissued to:
 - Add information on the 570B key service unit (KSU) and show the 570A rated MD
 - Add satelliting information using a nomograph or 14A1-100 terminal block
 - Indicate that the telephone sets and consoles used with COM KEY 718 are now supplied with ivory (-50) mounting cords instead of satin-silver (-87)
 - Change code of the K8 loudspeaker to KS-21880L1 and add information on the KS-21939L2 loudspeaker
 - Add information on use of 415A KTU-Automatic Private Line Circuit (570B only)
 - Add 77C apparatus mounting for floor mounting of 570-type KSU

- Add information on D-180720 Kit of Parts-used in 570A KSUs having a serial number of 16390 or lower and using a 478B KTU for TOUCH-TONE dialing
- Remove 19C3 power unit—570A KSUs were never supplied with the 19C3
- Change the rating of the 832A/2832A telephone sets from A&M Only to MD.

Since this reissue covers a general revision, arrows ordinarily used to indicate changes have been omitted.

1.03 This issue is based on:

- Section 463-341-102—Voice Connecting Arrangement FTP (33A Voice Coupler)
- Section 503-701-110-832- and 2832-Type Telephone Sets; Identification, Installation, Connections, and Maintenance
- Section 512-620-487—Speakerphone System—3-Type; 832-, 833-, 2832-, and 2833-Type Telephone Sets, Connections
- Section 512-740-471—Speakerphone System 4A, 832-, 833-, 2832-, and 2833-Type Telephone sets
- Section 518-010-105-KTS, Grounding and Special Protection Requirements
- CD- and SD-69652-01, Issue 4-7A Communication System Circuit
- CD- and SD-69654-01, Issue 3-832A and 2832A Telephone Circuit for Use With 7A Communication System
- CD- and SD-69656-01, Issue 2-6A1 and 6B1 Selector Console Circuit to Use With 7A Communication System.

If this section is to be used with equipment or apparatus reflecting a later issue of the drawing(s), reference should be made to the CDs and SDs to determine the extent of the changes and the manner in which the section may be affected.

2. DESCRIPTION OF APPARATUS

2.01 The 7A Communication System will accommodate a maximum of 7 CO/PBX lines and 18 stations. It is equipped with a 2-path intercom. A 570-type KSU houses a power supply and KTU mountings. Telephone sets (832- and 2832-type) are special 10-button, 11-button, and 13-button sets providing basic services such as pickup, hold and illumination, voice and tone signaling, multiline conferencing, and automatic button restoration (ABR). Optional features are privacy (lockout), privacy release, station restriction, paging [with or without customer-provided (CP) background music], power failure transfer, ring transfer, music-on-hold (utilizing CP music source). intercom preset conference, station busy console with direct station selection (DSS), station busy console with message waiting (MW), intercom-only telephone sets, TOUCH-TONE dialing, speakerphone. external signaling circuit, and connection to customer paging.

2.02 In the 7A Communication System, each station has access to all CO/PBX lines and both intercom paths. One station, selected as the attendant station (station code 0), is the only station factory-wired in the KSU for CO/PBX ringing. Incoming calls are answered at the attendant station. The attendant ascertains the station or party being called and places the incoming call on hold. The attendant may then page the called party or dial the called station or party over an intercom path and inform them of the incoming call. The attendant may reenter the call by depressing the associated line button. The attendant station (station code 0) is the only station that can divert its common audible ringing via the optional ring transfer feature. Any station may be optionally wired for CO/PBX ringing on a single line or for common audible ringing. Stations cannot be wired for both common audible and CO/PBX ringing. In the 7A Communication System, as many as ten stations may be wired for common audible ringing. Intercom station codes are 0 (attendant station code) and 3 through 19. Code 1 is a transfer digit for 2-digit codes and code 2 is for paging.

570-TYPE KSU

- 2.03 The 570A KSU (MD) (Fig. 1) has the following mechanical design features:
 - Contains an internally mounted 19C2A power unit (19C2 in some earlier models) and a KS-19175L1 interrupter
 - Contains five internally mounted 66-type connecting blocks for option, console, and station connections
 - Has fuse panel (Table A) which provides power distribution to connectors and station blocks for lamp and fusing functions
 - Has status lamps to indicate status of CO/PBX and intercom lines (Table B)
 - Has designation strip holder and tab assembly serving as a retainer to lock KTUs in the connectors
 - Mounts twelve 4-inch and three 8-inch KTUs
 - Has 424C, 455A, 456B, and 460B KTUs shipped with KSU
 - Is 25-1/2 inches wide, 17 inches high, 11 inches deep, and requires 9-1/2 inches of wall space on either side of the backboard to permit full opening of the carrier assemblies
 - Is arranged for wall mounting or may be floor-mounted (using the 77-type apparatus mounting)
 - Has a removable fiberglass cover.
- 2.04 The 570B KSU is the same as the 570A except:
 - No KTUs are shipped with the KSU-the 424C, 455A, 456B, and 460B KTUs must be ordered separately



Fig. 1-570-Type KSU (Cover Removed)

- Wired for use of a 498A KTU equipped with a 116A1 circuit module when music-on-hold is furnished—the 451-type KTU is not compatible with the 570B KSU
- Redesigned fuse panel using fuse clips instead of fuse holders (Fig. 6)
- J2 through J8 wired to A battery and A ground to permit use of 415A KTU (Automatic Private Line Circuit) when music-on-hold is not provided.

2.05 All wiring connections are made on connecting blocks located in the KSU (Fig. 2). Since all stations pick up all lines on the same button at each telephone set, all equipment connections are factory-wired to the connecting blocks.



All station connections are made on the station connection field blocks using standard color-code cutdown. This eliminates the need for an external cross-connection field except when using satellite wiring plan.

2.06 The block and column on which a station is cut down determines the intercom code assigned to that station. Intercom codes available are codes 0 and 3 through 19.

 (a) Connecting block 1 (Fig. 3) contains the diode arrangement for preset conference and common audible signaling. Terminals are provided for strapping the power failure transfer, CO ringing, preset conference, paging, and ring transfer.

-		~	-	
	$\boldsymbol{\alpha}$	н	-	•
	~	~	 -	~

FUSE ARRANGEMENT-570-TYPE KSU

1		-	FUSE PANEL (SEE	FIG. 6)				
FUSE DESIG NOTE 1)	FUSE A	MP ;)	POTENTIAL	FUNCTION				
F1				First CO/PBX Line Lamps				
F2		1		Second CO/PBX Line Lamps				
F3	1			Third CO/PBX Line Lamps				
F4	4 1-1/3(70A) 10V ac			Fourth CO/PBX Line Lamps				
F5				Fifth CO/PBX Line Lamps				
F6		-		Sixth CO/PBX Line Lamps				
F7				Seventh CO/PBX Line Lamps				
F8	1/2(700	3)		Interrupter Motor				
F9	1-1/3(70	DA)	-24V dc(SIG)	System Privacy and DSS Consol Paging Amplifier (Note 2)				
F10			10V ac	Ring Transfer and MW Console				
F11	1/2(700	3)	-94V do(81C)					
F12	3/4(70H	I)	-24V dc(SIG)	C Battery				
F13	1.1/9/7/		101/	First Intercom Path Lamp				
F14	1 1-1/3(7)	JA)	IOV ac	Second Intercom Path Lamp				
			POWER UNITS-19C2/	/19C2A				
FUS	E DESIG		FUSE AMP (TYPE)	FUNCTION				
Line F1			2(MDL-2)	AC Input Power				
±18V a	2		2(24C)	Console Lamp Supply				
±10V a	3		5(94F)	Lamp and Lamp Flash				
±10V a	2		0(241)	Lamp Wink				
24V dc	B SIG		3(24B)	B (Signal) Battery				
24V dc	A TLK		2(24C)	A (Talk) Battery				
			VOLTAGE RAN	NGES				
		-24/	A	18-26 (19C2, 19C2A)				
		-241	3	20-26 (19C2, 19C2A)				

Note 1: Early production models of the 570A KSUs were equipped with 16 fuses. Fuses 15 and 16 were used for music-on-hold.

Note 2: In the 570A KSU the paging amplifier is fed from fuse 11.

TABLE B

LINE STATUS LAMPS-570-TYPE KSU

LAMP	LAMP	FUNCTION
L1	51A	FIRST CO/PBX LINE LAMP
L2	51A	SECOND CO/PBX LINE LAMP
L3	51A	THIRD CO/PBX LINE LAMP
L4	51A	FOURTH CO/PBX LINE LAMP
L5	51A	FIFTH CO/PBX LINE LAMP
L6	51A	SIXTH CO/PBX LINE LAMP
L7	51A	SEVENTH CO/PBX LINE LAMP
L11	51A	FIRST INTERCOM PATH LAMP
L12	51A	SECOND INTERCOM PATH LAMP

(b) Connecting block 2 (Fig. 4) contains the polarity guard diodes for the CO/PBX lines.

(c) Connecting block 3 (Fig. 5) provides terminals for connecting station code 0 (attendant station), station code 3, the incoming CO/PBX lines, the optional message waiting or DSS consoles, and the 33A voice coupler.

(d) Connecting blocks 4 and 5 (Fig. 5) provide terminals for connecting station codes 4 through 19.

2.07 The fuse panel in the 570-type KSU utilizes 70-type indicator fuses to give a visual indication of fuse status. The 19-type power units are equipped with 24-type fuses which do not provide a fuse status indication. See Fig. 6 and Table A.

2.08 The lamp panel in the 570-type KSU provides a status lamp for each CO/PBX line and intercom path. The lamps give the same indication of line status (flash, steady, wink) as the line



TO SWING FULLY OPEN.





Fig. 3-Terminal Arrangement for Connecting Block 1

lamps in the telephone sets. See Fig. 6 and Table B.

CONSOLES

A. 6A1 Selector Console (Station Busy Console With DSS)

2.09 The 6A1 selector console (Fig. 7) is a 20-button console providing a 17-button DSS field with station busy lamps. Of the three remaining buttons, one is used as a paging button, one is used as an

intercom recall button, and one button is spare. Ivory (-50) is the standard console color, and a $6A2-\ddagger$ faceplate must be ordered with each console. Current 6A1 consoles are shipped with an ivory (-50) mounting cord rather than satin-silver (-87). The 6A1 selector console is normally used in addition to the attendant's telephone set to provide DSS on the intercom.

†Refer to Table C for color suffix.





ISS 4, SECTION 518-450-100

DSS CONSOLE 1	TERMINALS	1	INTERCOM STATION CODES									
MESSAGE WAITING CONSOLE TE	RMINALS	//	0 3	4 5 6 7 8 9 10 11	12 13 14 15 16 17 18 19							
	AB	CDE	FGH	ABCDEFGH	ABCDEFGH							
	10	8-8	0-01	100000001	10-0-0-0-0-01							
(0	0-0	0-0	0000000	0000000							
334	0	0-0	0-0	0000000	0000000							
VOICE	0	0-0	0-0	0000000	00000000							
COUPLER	50	0-0	0-05	500000005	50-0-0-0-0-05							
l	0	0-0	0-0	0000000	0000000							
	0	0-0	0-0	0000000	0000000							
	0	0-0	0-0	0000000	0000000							
	0	0-0	0-0	0000000	0000000							
	100	0-0	0-010	00000000000	100-0-0-0-0-010							
	0	0-0	0-0	0000000	0000000							
* FACTORY PROVIDED	0	0-0	0-0	0000000	0000000							
STRAP ON INSTALLER	0	0-0	0-0	0000000	0-0-0-0-0-0							
SIDE OF CONN BLK.	0	0-0	0-0	0000000	0000000							
	150	0-0	0-015	15000000000	1500000000							
	0	0-0	0-0	0-0-0-0-0-0	00000000							
	0	0-0	0-0	0000000	00000000							
	0	0-0	0-0	00000000	00000000							
	0	0-0	0-0									
	200	0-0	0-020	200-0-0-0-0-020	200-0-0-0-0-020							
	0	-	0-0	0-0-0-0-0-0	0-0-0-0-0-0							
	0	-	0-0	0-0-0-0-0-0								
	0	000	0-0	000000000								
	0	000	0-0	00000000	00000000							
	250	0-0	0-025	250-0-0-0-0-025	250-0-0-0-0-025							
	0	0 0	0-0	00000000	0-0-0-0-0-0							
	0	o*0	0-0	0000000	0000000							
	0	0 0	0-0	00000000	00000000							
	0	0 0	0-0	00000000	00000000							
	300	0 0	0-030	300-0-0-0-0-030	300-0-0-0-0-0-030							
	0	0 0	0-0	0000000	0000000							
	0	0 0	0-0	0000000	00000000							
	0	0 0	0-0	00000000								
	0	0 0	0-0	00000000	00000000							
	350	0 0	0-035	350-0-0-0-035	350-0-0-0-035							
	0	0 0	0-0	00000000	00000000							
(0	0 0	0-0									
	0	0 0	0-0	0-0-0-0-0-0								
	0	0 0	0-0	000000000								
	400	0 0	0-040	400-0-0-0-0-040	400-0-0-0-0-040							
	0	0 0*	0-0	00000000	00000000							
	0	0 0	0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0							
INCOMING CO/PBX	0	0 0	0-0									
LINE TERMINALS	0	0 0	0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0							
	450	0 0	0-045	450 0 0 0 0 0 045	450 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0							
	0	6 0	0 0	00000000	0 0 0 0 0 0 0 0							
	0	6 0	0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0							
	0	6 0	0-0	00000000	0000000							
	0	I c	0 0	0 0 0 0 0 0 0 0	00000000							
	500	I C	0 050	500 0 0 0 0 0 0 0 0								
L	pou	0.0	0 050	00000000000000	0000000000000							
		CONN BLK 3	3	CONN BLK 4	CONN BLK 5							

Fig. 5-Terminal Arrangement for Connecting Blocks 3, 4, and 5

- B. 6B1 Selector Console (Station Busy Console With MW)
- 2.10 The 6B1 selector console (Fig. 8) is a 20-button console providing a 17-button message waiting

field. Three buttons are not used. Ivory (-50) is the standard console color, and a $6A2-\dagger$ faceplate must be ordered with each console. Current 6B1

†Refer to Table C for color suffix.



Fig. 6—570-Type KSU, Connector, Fuse, and Lamp Arrangement

consoles are shipped with an ivory (-50) mounting cord rather than satin-silver (-87). The 6B1 selector console is normally used in addition to the attendant telephone set to provide the message waiting feature.

Note: Up to three selector consoles in any combination can be used in a 7A Communication System.

2.11 Console Power Requirements: If more than one console is to be used, lamp power (±18V, 2A) must be provided by a 215C1 power unit installed in the KSU or an equivalent external unit. The 215C1 has three ±18V outputs.



832-, 2832-TYPE TELEPHONE SETS SPEAKERPHONE, AND FACEPLATES LOUDSPEAKER, AND 6A1, 6B1 SELECTOR CONSOLES TRANSMITTER SUFFIX SUFFIX COLOR COLOR SUFFIX COLOR -100Avocado Black -03-108Teak (Woodgrain) Green --51 -109-58White Walnut (Woodgrain) -111 Gold Light Beige -60 -50Kit of Parts Ivory -112Orange Ivory D-180508* -113Brown -114Red -115 Blue -118 Black

TABLE C

* Order separately.

When it is installed in an earlier model KSU which has a 19C2 for the principal power unit, the $\pm 18V$ output of the 19C2 is disabled.

EXTERNALLY MOUNTED APPARATUS

A. 33A Voice Coupler

2.12 The 33A voice coupler (Fig. 9) is an interconnecting unit which provides a point of connection for a customer-provided music source used with music-on-hold and background music. It is wall-mounted externally from the KSU. A potentiometer (with screwdriver adjustment slot) controls the level of the background music. The unit contains two fuses for protection against hazardous voltages from the CP music source.

B. 20A-49 Apparatus Unit

2.13 The 20A-49 apparatus unit provides a point of connection or interface to a customer-owned and maintained (COAM) paging system. Also, the 20A-49 apparatus unit is used with a large high-power paging system provided by the telephone company.



Fig. 9-33A Voice Coupler

The unit is 1-13/16 inches deep by 2-3/4 inches high by 4-3/8 inches long and is wall-mounted externally to the 570-type KSU. It presents a load to the 457C KTU equivalent to one loudspeaker and provides an output impedance to the COAM equipment of approximately 300 ohms. The output is transmitted to the COAM paging equipment through a transformer which is both electrostatically and electromagnetically shielded to minimize the possibility of introducing noise. A potentiometer (with screwdriver adjustment slot) is provided to adjust the signal level. Connections are made on five screw terminals.

C. 22A-49 Apparatus Unit

2.14 The 22A-49 apparatus unit is an external signaling circuit that activates a signaling device which is external to the telephone sets. The 22A-49 apparatus unit offers a contact closure or opens a contact, as required, to operate KS-16301 type signaling devices (Section 463-110-100) or other external alerting devices. The unit is 1-13/16 inches deep by 2-3/4 inches high by 4-3/8 inches long and is wall-mounted externally to the 570-type KSU. Connections are made on six screw terminals. The 22A-49 apparatus unit may be used to activate an external signaling device for:

- · Common audible
- Station codes
- CO/PBX ringing
- Ring transfer.

D. KS-21880L1 Loudspeaker

2.15 The KS-21880L1 loudspeaker (Fig. 10) is an indoor speaker used for paging. It is 11 inches high, 10 inches wide, and 6-1/2 inches deep. It has a potentiometer (with screwdriver adjustment slot) for volume control. The KS-21880L1 loudspeaker is furnished with a walnut (woodgrain) finish. It was formerly known as the K8 loudspeaker. The speaker and the speaker enclosure are available as a List 2 and List 3, respectively, as repair or replacement parts.

E. KS-21939L2 Loudspeaker

2.16 The KS-21939L2 loudspeaker (Fig. 11) is a horn-type speaker used for paging at indoor

or outdoor locations. It is 7-1/2 inches in diameter, 7 inches deep, and weighs 3-1/4 pounds. The loudspeaker is equipped with a swivel mounting bracket having three holes in the outer rim for mounting on a flat surface. The loudspeaker will also fasten to a 1/2-inch pipe. Pigtail leads are provided for connections. Nominal frequency response of the loudspeaker is 400 to 13,000 Hz. The KS-21939L2 loudspeaker has a screwdriver adjusted volume control. It was formerly known as the KS-16846L2 loudspeaker. The KS-21939 loudspeaker is also available as a List 1 which is the same as the List 2 except it has no volume control, and as a List 3 which is the same as a List 2 except it is equipped with a rigid conduit mounting adapter.

2.17 The KS-21880 and the KS-21939 loudspeakers

are 45-ohm speakers. In the 7A Communication System, do not substitute speakers with other impedances for the two loudspeakers. Existing stocks of K8 or KS-16846L2 loudspeakers may be used.

KEY TELEPHONE UNITS

2.18 The circuitry for the 7A Communication System is provided by 400-series KTUs. Functional schematics are located in the rear of the section.

A. 400-Type KTU (CO or PBX Line Circuit)

2.19 The 400G KTU (Fig. 75) is a 4-inch unit which provides a key telephone set with CO or PBX line service. Additional information on the 400-type KTUs may be found in Section 518-215-400 (Line Services) and CD- and SD-69513-01 or CD- and SD-69942-01.

2.20 The latest version of the line circuit KTU is the 400H (Fig. 76). The 400G is also standard; all earlier 400-type KTUs are rated MD but can be used when available. The 400H can be mounted in any 570-type KSU with the following limitations.

• Do not install a 400H KTU in a 570A KSU (MD) when music-on-hold is required. Only the 451-type music-on-hold KTU can be used with the 570A KSU, and it is **not** compatible with the 400H.

SECTION 518-450-100



Fig. 10-KS-21880L1 Loudspeaker, Connections, and Mounting

- When a 400H (or any other 400-type line circuit) is installed in a 570B KSU, only the 498A KTU can be used to provide music-on-hold. The 451-type music-on-hold KTU is **not** compatible with the 570B KSU.
- B. 424A or B and 424C KTU (Dial Intercom, 19-Code Selector Circuit)
- 2.21 The 424A or B KTU is an 8-inch dial selective intercom unit. Additional information may



Fig. 11-KS-21939L2 Loudspeaker

be found in CD- and SD-69567-01. The 424C (Fig. 77) is the preferred KTU for replacements and new installations. In the 7A Communication System, the 424B/C KTUs provide the following:

- Rotary dial selection
- Nineteen dial codes (nine single-digit and ten 2-digit codes).

Note: In the 7A Communication System, the first digit of the 2-digit code is 1; therefore, 1 is not available as a station code. Code 2 is dedicated to paging which leaves codes 0 (attendant station) and 3 through 19 available for station codes.



Do not use a 424A KTU in the 7A Communication System.

C. 440A KTU (MD) (TOUCH-TONE Adapter Circuit)

2.22 The 440A KTU (Fig. 78) is a 8-inch unit that provides TOUCH-TONE dialing when used in conjunction with the 424B or C KTU. Additional information on the 440A KTU may be found in CD- and SD-69906-01. **Note:** The 440A KTU is superseded by an improved TOUCH-TONE adapter, the 478B KTU, which should be used for replacement and for new installations (see paragraph 2.29).

D. 451A or 451B KTU (Music-On-Hold Circuit)

2.23 The 451-type KTU (Fig. 79) is a 4-inch unit that is used with an externally mounted 33A voice coupler to connect a customer-provided source of music to a maximum of seven CO/PBX lines placed on hold. The 451A KTU was formerly identified as a 123A IU.



Install the 451-type KTU only in a 570A KSU containing 400G or earlier line circuits. If the KSU is a 570B, the 498A music-on-hold KTU equipped with a 116A1 CM must be used (see paragraph 2.30).

E. 452A KTU (Power Failure Transfer Circuit)

2.24 The 452A KTU (Fig. 80) is a 4-inch unit that automatically "cuts through" up to seven CO/PBX lines to external line ringers in the event of power failure.

F. 455A KTU (Tone Ringing Signal Generator Circuit)

2.25 The 455A KTU (Fig. 81) is a 4-inch unit that contains the tone ringing generator for CO/PBX signaling.

G. 456A or 456B KTU (Voice and Tone Alerting Circuit)

2.26 The 456-type KTU (Fig. 82) is a 4-inch unit that provides the following features on intercom calls:

- · Ringing tone to calling party
- · Tone alerting signal to called party
- Voice signaling to called party
- Input signal to paging amplifier.

The 456A will be rated MD but can be used in all installations where paging feedback or radio frequency interference are not problems. Paging feedback is, in general, an installation problem, and changeout to the 456B will help only in marginal cases.

H. 457C KTU (Paging Amplifier Circuit)

2.27 The 457C KTU (Fig. 83) is a 4-inch unit that contains the amplifier circuitry for paging and customer-provided background music. The customer-provided music source can be connected to the paging speakers when the paging circuit is not in use. The 457C KTU has a peak power output of 3 watts.

> Caution: The 457B KTU should not be used in lieu of the 457C KTU due to the likelihood of circuit failures.

I. 460B KTU (2-Path Intercom Access Circuit)

2.28 The 460B KTU (Fig. 84) is an 8-inch unit that contains two separate intercom paths. Path selection is based on operation of the associated intercom button on the key telephone sets. The unit also provides dial tone, seizes the selector, and provides a flashing lamp signal during selection and a steady lamp during the busy mode. Control circuitry permits only one intercom path to seize the selector a time.

J. 478B KTU (TOUCH-TONE Adapter Circuit)

2.29 The 478B KTU (Fig. 85) is an 8-inch unit that provides TOUCH-TONE dialing when used in conjunction with the 424B or C KTU. Additional information on the 478B KTU may be found in CD- and SD-69931-01.

K. 498A KTU (Music-On-Hold Circuit)

2.30 The 498A KTU (Fig. 86) is a 4-inch unit which provides music-on-hold for up to four CO/PBX lines when used in a 570B KSU. This KTU should always be equipped with a 116A1 CM when used in COM KEY in order to provide music-on-hold for up to seven lines. The 498A equipped with a 116A1 CM plugs into J18 on the KSU.



Do not install a 498A KTU in a 570A KSU. It is not electrically compatible.

KITS OF PARTS

2.31 Privacy (D-180486), Ring Transfer (D-180487),

Privacy Release (D-180488), and Recall (D-180591) Kit of Parts can be added to certain type 832 and 2832 telephone sets in the field. Refer to Table D for a summary of the features provided by these kits. Later model telephone sets have these features built in at the factory.

A. D-180486 Kit of Parts (Privacy)

2.32 The D-180486 Kit of Parts provides a privacy

or lockout feature. A station equipped with a privacy circuit is prevented from picking up a busy CO/PBX line. Intercom lines have no privacy.

B. D-180487 Kit of Parts (Ring Transfer)

2.33 The D-180487 Kit of Parts provides the feature for transferring incoming CO/PBX ringing from an attendant station to a designated secondary station. The D-180487 Kit of Parts adds an eleventh button (651C key) to the manufacture discontinued 832A or 2832A telephone sets.

C. D-180488 Kit of Parts (Privacy Release)

2.34 The D-180488 Kit of Parts provides the feature of permitting an excluded or locked-out station to enter a conversation on a busy CO/PBX line. The D-180488 Kit of Parts adds an eleventh button (651D key) to the 832A (MD) or 2832A (MD) telephone set.

D. D-180591 Kit of Parts (Recall)

2.35 The D-180591 Kit of Parts provides a station the feature of simulating a switchhook flash or recall. The D-180591 Kit of Parts adds an eleventh button to the 832A or 2832A telephone set. An 832A or 2832A telephone set equipped with the D-180591 Kit of Parts (recall) is electrically equivalent to the 832BM or 2832BM telephone set.

E. D-180656 Kit of Parts (Shelf for Wall Mounting Telephone Sets)

2.36 The D-180656 Kit of Parts provides a method

for wall mounting COM KEY telephone sets. This kit of parts consists of a shelf assembly (ivory colored) and a retaining clamp. The shelf will incline the telephone set 15 degrees from the horizontal to facilitate its use. This kit can be

used with any of the 832- or 2832-type telephone sets not already designed for wall mounting.

Note: When possible, sets designed for wall mounting should be used in preference to the D-180656 Kit of Parts.

TELEPHONE SETS

A. Full Service Telephone Sets (Table D)

2.37 The 832- and 2832-type telephone sets are 10-, 11-, or 13-button key telephone sets designed for use with the 7A Communication System. The sets are equipped with a loudspeaker for tone and voice signaling. A volume control is provided to control the level of the signal. Conferencing of two or more CO/PBX lines is accomplished by simultaneously depressing the buttons associated with the lines to be conferenced. The CO/PBX lines cannot be conferenced with intercom lines. Automatic button restoration (ABR) restores all depressed buttons when the handset is replaced. The lamp under the HOLD button is provided for use as a message waiting indicator.

Caution: The system may be disabled if multiple buttons are depressed at an idle station.

2.38 Full service telephone sets for the 7A Communication System are available in ivory (-50) only and are shipped from the factory with throwaway, protective faceplates. For each set, it is necessary to order a colored faceplate from the complement of nine vinyl-clad metal decorator faceplates that are available (see Table C). Current 832- and 2832-type telephone sets are shipped with an ivory (-50) mounting cord rather than satin-silver (-87).

832A/2832A (MD) Telephone Sets

2.39 The 832A telephone set is a rotary dial 10-button key set. The set has seven CO/PBX line pickup buttons, two intercom pickup buttons, and a HOLD button. The 832A telephone set may be modified in the field to provide a privacy circuit and either a PRIV RLS, RING TR, or RECALL button.

Note: Only one button (for privacy release, ring transfer, or recall) can be added to the 832A telephone set.

2.40 The 2832A set is the same as the 832A except it has a TOUCH-TONE dial.

832B/2832B (MD) Telephone Sets

2.41 The 832B telephone set is a rotary dial 11-button key set. The set has seven CO/PBX line pickup buttons, two intercom buttons, a HOLD button, and a RECALL button. The eleventh button, to the right and below the key assembly, is factory-wired for recall and is designated with an amber cap. A momentary operation of the RECALL button opens the line simulating a switchhook flash. The set may be modified in the field for privacy.

2.42 The 2832B set is the same as the 832B except it has a TOUCH-TONE dial.

832BM/2832BM Telephone Sets (Fig. 12)

2.43 The 832BM/2832BM 11-button telephone sets are the same as the 832B/2832B (MD) sets except that modular handset components are added.

832C/2832C (MD) Telephone Sets

2.44 The 832C telephone set is a rotary dial 13-button key telephone set. The set has a lower row of ten buttons for seven CO/PBX line pickups, two intercom line pickups, and for hold. The upper row contains three buttons on the left providing recall, privacy release, and (optional) ring transfer. A brushed aluminum finished collar assembly, with the words COM KEY in black letters, is positioned to the right of these buttons. The 832C telephone set is factory-wired with a privacy circuit and with the PRIV RLS button operational. The RING TR button is not factory-connected. An amber button cap is provided for the RECALL button, and an E-6406 designation strip is provided for labeling the RECALL, PRIV RLS, and RING TR buttons.

2.45 The 2832C set is the same as the 832C except it has a TOUCH-TONE dial.

832CM/2832CM Telephone Sets (Fig. 13)

2.46 The 832CM/2832CM 13-button telephone sets are the same as the 832C/2832C (MD) sets except that modular handset components are added.

TABLE D

7A COMMUNICATION SYSTEM TELEPHONE SET FEATURES

		10-BUTTON SETS	11-BUTTON SETS	13-BUTTON SETS
FEATURE	STATUS	832A (MD) 2832A(MD)	832B(MD) 832BM 832DM 2832B(MD) 2832BM 2832DM	832C(MD) 832CM 832EM 2832C(MD) 2832CM 2832CM 2832EM
-	Factory Provided		•	•
RECALL	Factory Connected		•	•
RECALL	Field Provided (Note 1)	•*		
	Field Connected	•		
	Factory Provided			•
PRIVACY	Factory Connected		a second and a second	
CIRCUIT	Field Provided (Note 2)	•		
	Field Connected	•	•	
	Factory Provided			•
PRIVACY	Factory Connected			•
RELEASE	Field Provided (Note 3)	•*		
	Field Connected	•	P.	
	Factory Provided			•
RING	Factory Connected			
TRANSFER	Field Provided (Note 4)	•*		
	Field Connected	•		•

Note 1: Kit of Parts D-180591

Note 2: Kit of Parts D-180486

Note 3: Kit of Parts D-180488

Note 4: Kit of Parts D-180487

* Only one of these features can be added to one 832A or 2832A set.

ISS 4, SECTION 518-450-100



Fig. 12-832BM-50 Telephone Set

832DM/2832DM Telephone Sets

2.47 The 832DM/2832DM 11-button telephone sets are the same as the 832BM/2832BM except that they are arranged for wall mounting. The switchhook allows the handset to hang vertically to the left of the housing.

832EM/2832EM Telephone Sets (Fig. 14)

2.48 The 832EM/2832EM 13-button telephone sets are the same as the 832CM/2832CM except that they are arranged for wall mounting.

B. Intercom Only Telephone Sets

575AM Telephone Set

2.49 The 575AM telephone set is a rotary dial, ivory color, 6-button key set arranged for intercom service only. It is similar to the 565-type set in physical appearance. The set is equipped with a loudspeaker for tone and voice signaling. A volume control is provided to control the level of the signal. The first button (hold button position) is a red nonfunctional button (blocked nonoperative) which may be illuminated for use as a message



Fig. 13-2832CM-50 Telephone Set

waiting indicator. The second, third, and fourth (not used with 7A Communication System) buttons are illuminated pickup buttons. The fifth and sixth are not illuminated and are blocked nonoperative.

2.50 As shipped from the factory, only two . intercom buttons (buttons two and three) are wired operational as required for use with the 7A Communication System.

2.51 The intercom pickup buttons on the 575AM telephone set do not automatically restore to the nonoperated position when the handset is placed on-hook.

2575AM Telephone Set

2.52 The 2575AM telephone set is the same as the 575AM telephone set except it is equipped with a TOUCH-TONE dial.

3. INSTALLATION

PLANNING

3.01 Survey the area to be served by the 7A Communication System. Select a location for the 570-type KSU that:

• Provides a safe working location



Fig. 14-832EM-50 Telephone Set

- Has customer's approval and is in his best interest
- Has adequate light and is always accessible
- Has a wall providing adequate support and stability, or floor space away from foot traffic and protected from vehicular traffic
- Has sufficient clearance above floor level to avoid damage from water or blows incidental to cleaning
- Is central to station locations to permit shortest cable runs
- Is clean, dry, well-ventilated, and free from corrosive fumes
- Is not subject to extreme temperatures
- Is near a commercial ac power receptacle not controlled by a switch.



Allow at least 9 inches of space in front of and on each side of KSU to permit gates to swing open.

3.02 Arrangements should be made for the customer to provide a commercial ac power receptacle in accordance with the following:

- Not under control of a switch
- · Separately fused
- Receptacle should be grounded 3-wire type.
- 3.03 Select appropriate apparatus according to job requirements.

Caution: The paging feature of the 7A Communication System can be inadequate for paging in noisy locations. A preinstallation survey should be made of noisy areas where paging is to be provided. The results of the survey may indicate:

- Additional speakers located closer together will be required
- An auxiliary paging system (telephone company or customer provided) will be required.

An auxiliary paging system requires the use of a 20A-49 apparatus unit.

ORDERING GUIDE

- (a) Apparatus for Basic Service:
 - Unit, Service Key, 570B (No KTUs are furnished with the KSU; order required KTUs separately.)

Cord, Power (order required length)

824013288 (P-40J328) (4 feet)

824013296 (P-40J329) (6 feet)

824010995 (P-40J099) (12 feet)

• Mounting, Apparatus, 77C (floor stand for 570-type KSU; order one per installation when KSU is to be floor-mounted)

- Unit, Telephone Key, 400G (CO/PBX line circuit) (order one per line for use in 570A or B KSU)
- Unit, Telephone Key, 400H (CO/PBX line circuit) (order one per line for use in 570B KSU or in 570A KSU when music-on-hold is not required)
- Unit, Telephone Key, 424C (Dial Intercom, 19-Code Selector Circuit)
- Unit, Telephone Key, 455A (Tone Ringing Signal Generator Circuit)
- Unit, Telephone Key, 456A or 456B (Voice and Tone Alerting Circuit)
- Unit, Telephone Key, 460B (2-Path Intercom Access Circuit).

11-Button Sets:

- Set, Telephone (desk), 832BM-50 (rotary dial) or 2832BM-50 (TOUCH-TONE dial)
- Set, Telephone (wall), 832DM-50 (rotary dial) or 2832DM-50 (TOUCH-TONE dial)
- Plate, Face, 832B-[†] (order one for each 832BM or 832DM telephone set)
- Plate, Face, 2832B—[†] (order one for each 2832BM or 2832DM telephone set).

13-Button Sets:

- Set, Telephone (desk), 832CM-50 (rotary dial) or 2832CM-50 (TOUCH-TONE dial)
- Set, Telephone (wall), 832EM-50 (rotary dial) or 2832EM-50 (TOUCH-TONE dial)
- Plate, Face, 833A-† (order one for each 832CM or 832EM telephone set)
- Plate, Face, 2833A-† (order one for each 2832CM or 2832EM telephone set).

Intercom-Only Sets:

- Set, Telephone, 575AM (rotary dial)
- Set, Telephone, 2575AM (TOUCH-TONE dial)

- Cable, Connector, A25B (order one single-ended cable per telephone set and console used; length must be specified).
- (b) Optional Apparatus (Order as Required):
 - Console, Selector, 6A1-50 (Station Busy Console with DSS)
 - Console, Selector, 6B1-50 (Station Busy Console with MW)
 - Coupler, Voice, 33A (order when background music or music-on-hold is provided)
 - Diode, 446F, or equivalent (order one for each rotary dial station to be restricted)
 - Kit of Parts, D-180486 (Privacy Circuit) (order one for each 832/2832A, B, BM, or DM type telephone set to be locked out)
 - Kit of Parts, D-180487 (Ring Transfer) (order one for each 832A or 2832A telephone set used as attendant station)
 - Kit of Parts, D-180488 (Privacy Release) (order one for each 832A or 2832A telephone set used for a station equipped with the privacy release feature)
 - Kit of Parts, D-180591 (Recall) (order one for each 832A or 2832A telephone set used as a station equipped with the recall feature)
 - Kit of Parts, D-180656 (Shelf Assembly) (order one for each 832/2832A, B, C, BM, or CM type telephone set to be wall-mounted)
 - Loudspeaker, Horn, KS-21939L2 (order as required for outside paging)
 - Loudspeaker, Indoor, KS-21880L1 (order as required for indoor paging)

Note: A maximum of seven paging loudspeakers can be connected to the 7A Communication System.

• Ringer, E1C (order one for each line to be wired for power failure ringing)

†Refer to Table C for color suffix.

• Speakerphone, 3B (order one each for each station to be equipped)

Cord, D10R-† (specify length: 1 foot 4 inches, 9, 12, or 25 feet)

Loudspeaker, 760A-†

Transformer, 2012B

Transmitter, 666B-†

Unit, Control, 55B

• Speakerphone, 4A (order one each for each station to be equipped)

Adapter, 223-A-49 (includes M16C and M2FG cords)

Loudspeaker, 108-7

Transmitter, 680A-T

Unit, Power, 85B1-49

†Refer to Table C for color suffix.

- Unit, Apparatus, 20A-49 (order when 7A Communication System is connected to a customer's paging system or connected to a separate paging system provided by the telephone company)
- Unit, Apparatus, 22A-49 (order when signaling devices, external to telephone sets, are required) (Signaling devices, bells, buzzers, gongs, etc, and an external power supply must be ordered as required.)
- Unit, Telephone Key, 440A or 478B (TOUCH-TONE Adapter Circuit)

Note: J13/J14 connector on KSU must have A and B ground connected when 478B KTU is used. Do not use 478B KTU in conjunction with any dial intercom selector circuit except 424C.

• Unit, Telephone Key, 451A or 451B (Music-On-Hold Circuit) (order one per system in which 400G or earlier line circuits are used with 570A KSU)

- Unit, Telephone Key, 452A (Power Failure Transfer Circuit)
- Unit, Telephone Key, 457C (Paging Amplifier Circuit)
- Unit, Telephone Key, 498A (Music-On-Hold Circuit) (order one per system in which 400H line circuits are used with 570B KSU; provides music for up to four CO/PBX lines)
- Module, Circuit, 116A1 (Music-On-Hold Circuit daughter board) (order one per 498A KTU).
- (c) Replaceable Components:

570-Type KSU:

- Fuse, 24B (3A)
- Fuse, 24C (2A)
- Fuse, 24F (5A)
- Fuse, 70A (1-1/3A)
- Fuse, 70G (1/2A)
- Fuse, 70H (3/4A)
- Interrupter, KS-19175L1
- Lamp, 51A
- Unit, Power, 19C2A
- Unit, Power, 19C2 (on earlier models of 570A KSU).

33A Voice Coupler:

- Fuse, 35P (3/4A).
- 832- and 2832-Type Telephone Sets:
- Refer to Section 503-701-110.

575AM and 2575AM Telephone Sets:

- Cord, D20P-87 (mounting cord)
- Cord, H4DU-50 (handset cord)
- Dial, 9CA (rotary dial)

- Dial, 35Y3A (TOUCH-TONE dial)
- Housing, 840996268 (rotary set) or 840997258 (TOUCH-TONE set)
- Key, 636A
- Lamp, 51A
- Plate, Face, 840845502 (required only for TOUCH-TONE set)
- Set, Hand, G15A-50.

6A1 and 6B1 Selector Consoles:

- Base, 6A1 (for 6A1 Selector Console)
- Base, 6B1 (for 6B1 Selector Console)
- Cord, Mounting, D50AD-50
- · Housing, 6A1-50
- Key, 647J5 (for 6A1 Selector Console)
- Key, 647AG5 or 647J5C (for 6A1 Selector Console)
- Key, 647AF5 or 647C5 (for 6B1 Selector Console)
- Lamp, 51A
- Plate, Face, 6A2-†

†Refer to Table C for color suffix.

INSTALLING

- 3.04 Be careful when unpacking to prevent damage to components.
- 3.05 Install the 7A Communication System as follows.
- A. 570-Type KSU
 - (1) Remove cover from KSU.
 - (2) Use the template provided to locate the fastener holes at the selected location.
 - (3) Install appropriate fasteners.

Page 24

(4) Hang KSU on fasteners.

(5) Connect the circuit ground to an acceptable ground. For circuit ground, a No. 14 gauge wire should be attached from the LOC GRD terminal of the power unit to an acceptable local ground. If a 3-wire grounded receptacle is not available, a frame ground (No. 14 gauge wire) must be connected from the case or frame of

the power unit to an acceptable local ground.

Caution: Do not strap the circuit ground to the frame or case of the power unit. The susceptibility of surge damage to semiconductor components used in 400-series KTUs requires that grounding procedures be followed. Properly grounded installations will minimize service failures that can result from surge voltages or differences between dissimilar grounds. Refer to Section 518-010-105 for detailed information on grounding key systems.

- (6) Unlatch and open carrier assemblies.
- (7) Terminate the incoming CO/PBX lines on connecting block 3 as shown in Fig. 15.
- (8) Terminate the station cables. Cut down the A25B connector cables on connecting blocks 3, 4, and 5 as shown in Fig. 16. Intercom station code 0 (attendant station) is terminated on column G of connecting block 3. Intercom station code 3 is terminated on column H of connecting block 3, and station codes 4 through 19 are terminated on columns A through H on connecting blocks 4 and 5 as shown in Fig. 16. A direct cable run to any station may not exceed 667 feet of 24-gauge cable.
- (9) Place or remove option straps.
- (10) Install power cord. Do not connect to ac source at this time.
- (11) Close and latch carrier assembly.
- (12) Install KTUs necessary to provide required services. See Fig. 6 for KTU connector arrangement.



Fig. 15-Connections for Incoming CO/PBX Lines

B. Satellite Wiring Plan

3.06 The 7A Communication System is designed for Home-Run cabling (direct cabling) from each telephone set to the KSU. Where it is more practical to serve a group of stations from a secondary location, a satellite wiring plan can be used. The satellite wiring plan is a connecting block arrangement for station terminations. It is served by a connecting cable or cables from the KSU.

3.07 Cabling is required between the KSU and the satellite location to provide the following leads:

- Those leads common to all stations, such as T, R, and A of the CO/PBX lines, T and R of the intercoms, etc. Only one appearance of these leads is required at the satellite.
- Six leads for *each* station code working from the satellite location. These are the VS, CO, SB, ±10V, ET, and ER leads.
- Additional leads required to cover A1, lamp, and lamp ground restrictions. These

restrictions limit the voltage drop in the lamp loop to less than 2 volts and require a low resistance A to A1 lead.

3.08 Two methods are covered for providing the proper amounts of terminations and leads at a satellite location. One method employs a prewired 14A1-100 terminal block. The second uses standard 66-type connecting blocks and a nomograph which help to determine the number of extra lamp and lamp ground leads required.

3.09 All satellite wiring arrangements should limit the total distance from the KSU to

the satellite **plus** from the satellite to the station to 667 feet.

C. Satellite Plan Using a 14A1-100 Terminal Block

3.10 The 14A1-100 terminal block consists of a

66-type connecting block factory-wired to four microribbon connectors. One 14A1-100 terminal block will accommodate eight 25-pair station cables. Station cables are terminated on the 66-type connecting block columns following the even-count color code.

3.11 Connections between the terminal block and the KSU are made using connector cables plugged into the connectors on the block. The other end of the cables are terminated in the KSU, as shown in Fig. 17, on the rows and columns of the KSU that would normally contain the station cables.

3.12 For the purpose of illustration, assume a satellite installation made up of station codes
4, 6, 8, 10, 12, and 14. Since one 14A1-100 terminal block will accommodate eight satellite stations, space is available for growth of two stations. In this case, the cables from stations 4, 6, 8, 10, and 12 are terminated on columns A through E, respectively, of the terminal block. Station 14 is terminated on column H, leaving columns F and G as spares.

Note: One of the station codes involved in the satellite installation must always be terminated on column H since this column contains the leads common to all the satellite stations, such as the tips and rings.

	A25B CONN CABLE			INTERCOM STATION CODES														
	COLOR	LEAD DESIG	0+	+3	4	5	6	7	8 9	10	11	12	13	14	15	16 1	7 18	3 19
	(W-BL)	TI	FG	н	A	B	C	D	EF	G	H	A	в	C	D	EF	G	н
	(BL-W)	RI	-0	-01	10-	-0-	0	~	0-0	-0-	-01	10-	-0-	-0-	0	~	0	-01
	(W-0)	LI	0	-0	0	-0-	0	0	0-0	-0-	-0	0	-0-	~	0	~	b	-0
	(0-W)	IA	0	-0	0	-0-	0	0	00	-0-	-0	0-	-0-	0	0	~	-	-0
	(W-G)	12	-	-0	0-	-0-	0	0	0-0	-0-	-0	0	-0-	-0-	0	~	-0	-0
	(G-W)	R2	-0-	-05	50-	-0-	-0-	0	00	-0-	-05	50-	-0-	-0-	-	~	>0	-05
	(W-BR)	L2		-0	0-	-0-	-0-	0	0-0	-0-	-0		-0-	-0-	-	~	~	-0
	(BR-W)	24		-0	0-	-0-	-	-	0-0	-0-	-0	0-	-0-	-	-	~		-0
	(W-5)	T3		-0	0-	-0-	-0-	-	0-0	-0-	-0	0-	-0-	-0-	0	0		-0
	(S-W)	R3	0	-0	0-	-0-	0	0	0-0	-0-	-0	0-	-0-	0	0	0		-0
	(R-BL)	L3	10	-010	100-	-0-	-0-	0	0-0	-0-	-010	100-	-0-	-0-	-	0	10	-010
	(BL-R)	3A	-0-	-0	0	-0-	-	0	00	-0-	-0	0-	-0-	-	-	0	~	-0
	(R-0)	T4	0	-0	0	-0-	-0-	0	0-0	-0-	-0	0-	-0-	0	-	~		-0
	(0-R)	R4	-0-	-0	0	-0-		0	0-0	-0-	-0	0-	-0-	-0-	0	0	\sim	-0
	(R-G)	L4	-0-	-0	0-	-0-	-0-	-	0-0	-0-	-0	0-	-0-	-0-		0		-0
	(G-R)	4A	-0	-015	150-	-0-	-0-	0	0-0	-0-	-015	150-	-0-	0	0	0		-01
	(R-BR)	T5	0	-0	0-	-0-	-0-	-	0-0	-0-	-0	0	-0-	0	0	0		-0
	(BR-R)	R5	-0	-0	0	-0-	-0-	0	00	-0-	-0	0	-0-	-0-		0		-0
	(R-S)	L5	10	-0	0-	-0-	-0-	0	0-0	-0-	-0	0	-0-	-0-	-	~		-0
	(S-R)	5A	0	-0	0-	0		0	00	-0	-0	0-	-0-	-0-	0	0		-0
	(BK-BL)	T6		-uzu	200-	~	~	~	000		-024	200-	~	~	~	~	~	-ue
	(BL-BK)	R6		~	0	~	~	~	~	~	~		~	~	~	\sim		
	(BK-0)	L6		~		~	~	~	~	~	~		~	~	~	~	~	_
	(0-BK)	6A		~	1 ~	~	~	~	~	~		12	~	~	~	\sim	\sim	
TO KEY	(BK-G)	17		-025	250		~	~	~		025	250	~	~	~	~	-	
TELEPHONE SET	(G-BK)	R7		-0	0	-0-	-	0	-	-0	-0	0	-0-		0	-	-	-0
	(BK-BR)	L7		-0	0-	-0-		-	0-0	-0-	-0	0	-0-	-0-	-	-	-0	-0
	(BR-BK)	7A	-	-0	0-	-0-	-0-	-	0-0	-0-	-0	0	-0-	-0-	-	-	-0	_
	(BK-S)	ITI	-0	-0	0-	-0-	-	-	0-0	-0	-0	0-	-0-	-0-	-	-	-	_0
	(S-BK)	IRI	-0	-030	300-	-0-	-0-	-	0-0	-0	-030	300-	-0-	-0-	-	0	-0	-03
	(Y-BL)	ILI	-0	-0	0	-0-	-0-	-	0-0	-0-	-0	0-	-0-	-0-	-0-	-	-0	-0
	(BL-Y)	LG	-	-0	0-	-0-	-0-	0	0-0	-0-	-0	0	-0-	-0-	-0-	0	-0	-0
	(Y-0)	IT2	-	-0	0-	-0-	-0-	0	0-0	-0	-0	0	-0-	-0-	-0-	0		-0
	(0-Y)	IR2	-0	-0	0-	-0-	-0-	0	00	-0-	-0	0	-0-	-0-	-0-	0	-0	-0
	(Y-G)	IL2	0	-035	350-	-0-	-0-	-	0-0	-0-	-035	350-	-0-	-0-	-0-	0	-	-03
	(G-Y)	LG	-0	-0	0-	-0-	-0-	-	0-0	-0-	-0	0-	-0-	-0-	-	0	-0	-0
	(Y-BR)	AI	0	-0	0-	-0-	-0-	-	0-0	-0-	-0	0	-0-	-0-	-0-	-	-0	
	(BR-Y)	LG	0	-0	0	-0-	-0-	0	0-0	-0-	-0	0	-0-	-0-	-0-	0	-0	-0
	(Y-S)	LG	0	-0	0	-0-	-0-	0	00	-0-	-0	0	-0-	0	-	~	-	-0
	(S-Y)	LG		-040	400-	-0-	-0-	0	0-0	-0-	-040	400-	-0-	-0-	0	0	-0	-04
STATION	(V-BL)	A GRD	0	-0	0-	-0-	-0-	0	0-0	-0-	-0	0-	-0-	-0-	0	0	-0	-0
CODE O IS	(BL~V)	VST	0	0	0	0	0	0	0 0	0	0	0	0	0	0	0 0	0 0	0
DEDICATED	(V-0)	CBAT	-0	-0	0-	-0-	-0-	-	0-0		-0	0-	-0-	-0-	-0-	0	-	-0
TO THE	(0-V)	COF	10	0	0	0	0	0	0 0	0	0	0	0	0	0	0 0	0 0	0
ATTENDANT	(V-G)	B GRD	-0	-045	450-	-0-	-0-	0	0-0	-0-	-045	450-	-0-	-0-	0	0	00	-04
STATION	(G-V)	NIT OR SBT	-	0	0	0	0	0	0 0	0	0	0	0	0	0	0 1	0 0	0
RING	(V-BR)	10V1 + (LIO)	-	0	0	0	0	0	0 0	0	0	0	0	0	0	0	0 0	0
TRANSFER	(BR-V)	BBAT	10	-0	0	-0-	-0-	0	00	-0-	-0	0	-0-	-0-	0	0	0-0	-0
(RT) IS ON	(V-5)	LIOT	10	0	0	0	0	0	0 0	0	0	0	0	0	0	0 1	0 0	0
CONN BLK 3.	(S-V)	EROŦ	10	050	500	0	0	0	0 0	0	050	500	0	0	0	0	0 0	05
COL G ONLY.	SED STATIO	N MUST P/	O CONN	BLK 3	000	-	CO	NN E	BLK 4	-		[made	-	CO	NN E	BLK	5	-

BE RUN SEPARATELY WHEN SATELLITE ARRANGEMENTS ARE USED (STATIONS 3-19)



After the cables are terminated, B bridging clips must be placed as shown in Fig. 18 to tie the lamp and lamp ground leads together.

3.13 Connector cables are plugged into the connectors of the terminal block and routed to the KSU. The cables are terminated in the

KSU as shown in Fig. 17. For this example, the cable from connector No. 1 is terminated where the cable for the station appearing on column H of the terminal block (code 14) would be terminated if home run; eg, block 5, column C of the KSU. Cable No. 2 provides the additional lamp and lamp ground leads, plus the individual code leads, for

the stations on column G (spare) and column A (station code 4) of the 14A1-100 terminal block so the leads for code 4 are terminated on block 4, column A. In addition, the four A1 leads can be obtained on any of the spare terminations of the satellite stations. Cables 3 and 4 are terminated in a like manner on the designated blocks and columns.

D. Satellite Plan Using Nomograph

3.14 The same basic rules used with the 14A1-100 terminal block apply for satellites using standard 66-type connecting blocks. Sufficient conductors must be run from the KSU to the satellite to provide a one-time appearance of all common station leads, individual code leads, and enough L and LG multiples (see paragraph 3.07).

3.15 The number of additional conductors required per L and LG lead is determined using the nomograph shown in Fig. 19. To use the nomograph, it is necessary to know three items:

- (a) The distance from the KSU to the satellite location
- (b) Number of stations to work from the satellite
- (c) Distance from satellite location to farthest station working from satellite.

By plotting the values on the proper scales and connecting them, the required number of additional conductors required per L and LG lead can be determined. The three required values are plotted on scales A, B, and E, respectively, in Fig. 19. The number of additional leads required per L and LG lead will be found on scale D. Scales C1 and C2 are used only to establish reference points.

3.16 To illustrate the use of the nomograph, assume a satellite location is 400 feet from the KSU, eight stations are to be fed from the satellite, and the farthest station is 175 feet from the satellite. These figures are used as an example shown in Fig. 19 and are shown as dotted lines. To determine the number of extra leads required, use the nomograph as follows:

(1) Locate the distance from the KSU to the satellite on scale A (400 feet).

(2) Locate number of stations served by satellite on scale B (8 stations).

(3) Using a straight edge, connect the points on A and B and extend the line until it crosses scale C1.

- (4) Note the point at which the line crosses C1 (approximately 33); find the same point on C2 and mark.
- (5) Locate the distance from the satellite to the farthest station (175 feet) on scale E.
- (6) Using a straight edge, connect points on C2 and E.

(7) The point where the line from C2 to E crosses scale D indicates the number of additional conductors required (6 in the example) for each L and LG lead.

E. Telephone Sets

3.17 Install telephone sets at desired locations. Install any telephone set options at this time. Refer to Section 503-701-110 for schematics and additional information on the 832- and 2832-type telephone sets. For information on the 575AM and 2575AM telephone sets, refer to Section 503-603-120.



3.18 Where a wall-mounted telephone is desired,

install either a wall-type set (832/2832DM or EM) or a D-180656 Kit of Parts for converting desk sets to wall sets. The method of mounting wall-type sets is illustrated in Fig. 20. The D-180656 Kit of Parts (Fig. 21) consists of a mounting shelf and a telephone set retaining clamp. Install the mounting shelf using appropriate fasteners for the surface on which it is to be mounted. Insert the telephone set mounting cord down through the opening at the rear of the shelf. Insert the retaining

SECTION 518-450-100

	14A1-100 TERMINAL BLOCK CONNECTOR 1	CONNECTO CABLE 1	R		KSU TERMINAL
CONN. BLOCK TERMINAL		LEAD DESIG	COLOR		
1A-H		NOCH TI	(W-BL)	1	1
2A-H		R1	(BL-W)	2	
ЗН		277 L1	(W-O)	3	
4A-H		12 1A	(O-W)	4	10
5A-H		28 12	(W-G)	5	
6A-H		3 R2	(G-W)	6	
<u>7H</u>		29 12	(W-BR)	7	
8A-H		A 2A	(BR-W)	8	
9A-H		30 73	(W-S)	9	
10A-0		5 XR3	(S-W)	10	
0 11H		31) L3	(R-BL)	110	
- 12A-H)6) 3A	(BL-R)	120	
13A-H		>32> 14	(R-O)	13	
0-14A-H		\rightarrow 7 > R4	(O-R)	14	
0 15H		>33> L4	(R-G)	15	
0 16A-H		$\rightarrow 8 \rightarrow 4A$	(G-R)	16	
0 10A U		>34> 15	(R-BR)	17	1
0-10H		\rightarrow 9 > R5	(BR-R)	18	point find a
0 19H			(R-5)	19	
0 21A H		$\rightarrow 10 > 5A$	(S-R)	20	TERMINA
0-22A-H		>36>16	(DK-DL)	210	ON BLOC
0 000			(BL-BK)	220	FOR STA
0 244-H			(DK-U)	230	TERMIN/
0 25A-H			(BK-G)	250	H OF 14
0 26A-H		>38> 17	(G_BK)	26	TERMINA
0 27H		$\rightarrow 13 \rightarrow 17$	(BK-BR)	27	1
28A-H			(BR-BK)	28	
29A-H		\rightarrow 14) II1	(BK-S)	29	
° 30A-H			(S-BK)	30	
° 31H		> 15 III 1	(Y-BL)	310	
° 32H		41) ACG1	(BL-Y)	32	
° 33H) 16) II2	(Y-D)	33	
34H		12) IR2	(O-Y)	34	
35H		II IL2	(Y-G)	35	
36H		ACG2	(G-Y)	36	
37F-H		18 A1	(Y-BR)	37	
38H		ACG3	(BR-Y)	38	
39H	A CARLES AND AND AND A	ACG4	(Y-S)	39	
40H		ACG5	(S-Y)	40	200.00
41H		AG A GND	(V-BL)	41	1.1.1
42H	and the second second	NO1 VS	(BL-V)	42	1.00
43H		AT C BAT	(V-O)	43	
44H		22 00	(0-V)	44	
45H		AR B GND	(V-G)	45	
46H		23 SB	(G-V)	46	
47H		>49 ±10V	(V-BR)	47	
48H		B BAT	(BR-V)	48	
49H		>50 ET	(V-S)	49	
50H		25 ER	(S-V)	50	
-		1		1	

TERMINATE IN KSU ON BLOCK AND COLUMN FOR STATION CODE TERMINATED ON COLUMN H OF 14A1-100 TERMINAL BLOCK

Fig. 17-Connections for 14A1-100 Terminal Block (Sheet 1 of 4)

14A1-100 TERMINAL BLOCK CONNECTOR 2	CONNECT	OR 2	KSU TERMINAL				
CONN. BLOCK	LEAD	01.00					
TERMINAL	DESIG	OULON					
36	26 L1	(W-BL)	3				
76	1 L2	(BL-W)	7				
116	27 L3	(W-O)	11				
156	12 14	(U-U)	15				
196	28 L5	(W-G)	19				
236	13 16	(G-W)	23				
276	129 L7	(W-BR)	270				
316	IL1	(BR-W)	31 TERMINATE IN KSU				
326	ACG1	(W-S)	32 ON BLOCK AND COLUMN				
356	IL2	(S-W)	35 FOR STATION CODE				
366	ACG2	(R-BL)	36 TERMINATED ON COLUMN				
386	ACG3	(BL-R)	38 G OF 14A1-100				
396	ACG4	(R-O)	39 TERMINAL BLOCK				
40G	ACG5	(O-R)	40 0				
42G	VS	(R-G)	420				
44G	>33 \ C0	(G-R)	44 0				
466	>8 > SB	(R-BR)	46				
° 47G	>34> +10V	(BR-R)	470				
496	->9 > FT	(R-S)	490				
506		(S-R)	50 0				
° 3A-C	$\rightarrow 10 > 11$	(BK-BL)	300				
°7A-C		(BI_BK)	70]				
0 114-0	$\rightarrow 11 \rightarrow 12$	(DL-DK)	110				
0 154 0		(0,00)	150				
0 104-0		(U-BK)	100				
0 224 0	>38>10	(BK-0)	000				
0 074 0	>13> 13	(G-BK)	970				
0 214 0	>39> 114	(BK-BK)	010				
0 004 0	>14>111	(BR-BK)	31 000				
0 32A-U		(BK-S)	DEO TERMINATE IN KSU				
35A-C	\rightarrow 15 > 122	(S-BK)	35 ON BLOCK AND COLUMN				
0-36A-C		(T-BL)	36 FOR STATION CODE				
0 38A-C		(BL-Y)	38 TERMINATED ON COLUMN				
- 39A-C	22 ACG4	(Y-O)	39 A OF 14A1-100				
40A-C	17 ACG5	(O-Y)	40 TERMINAL BLOCK				
42A-C	43 VS	(Y-G)	42				
044A-C	18 00	(G-Y)	44				
46A-C	A4 SB	(Y-BR)	46				
47A-C	> 19 ± 10V	(BR-Y)	47				
49A-C	AS ET	(Y-S)	49				
50A-C	20 ER	(S-Y)	50				
37F-H	ALC A1	(V-BL)	37				
37A-C	A1	(BL-V)	37 TERMINATE IN KSU ON				
37A-C	AT A1	(V-O)	37 ANY STATION CODES				
37D-E	202 A1	(0-V)	37 IN SATELLITE				
	222	(V-G)					
0	48>	(G-V)	-0				
0	>23>	(V-BR)	0				
0	>49>	(BR-V)	-0				
0	>24>	(V-S)	-0				
0	\rightarrow 50 >	(S-V)	0				
0		10.1	0				

Fig. 17-Connections for 14A1-100 Terminal Block (Sheet 2 of 4)

14A1-100 TERMINAL BLOCK CONNECTOR 3	1	CONNECTOR CABLE 3		KSU TERMINAL				
CONN. BLOCK TERMINAL	-	LEAD	COLOR					
3A-C	1	1	(W-BL)	3 7				
° 7A-C	$\rightarrow 26 \rightarrow 1$	2	(BL-W)	70				
° 11A-C	$\rightarrow 1 \rightarrow 1$	3	(W-O)	110				
0 15A-C		4	(O-W)	150				
9A-3		5	(W-G)	19 [°]				
23A-C	->28>L	6	(G-W)	230				
27A-C		7	(W-BR)	27°				
31A-C	->29>I	L1	(BR-W)	31	TEDMINATE IN KOU			
32A-C	->4 >A	CG1	(W-S)	32	ON BLOCK AND COLUMN			
35A-C	J	L2	(S-W)	35	FOR STATION CODE			
36A-C		CG2	(R-BL)	36	TERMINATED ON COLUMN			
38A-C		CG3	(BL-R)	38	B DF 14A1-100			
39A-C		CG4	(R-0)	39	TERMINAL BLOCK			
40A-C		CG5	(O-R)	40				
° 42B		S	(R-G)	420				
44B		0	(G-R)	44				
468		B	(R-BR)	46				
° 478	34	10V	(BR-R)	47				
° 49B		T	(R-S)	49				
50B		R	(S-R)	50				
3A-C		.1	(BK-BL)	3 %				
7A-C		.2	(BL-BK)	7				
11A-C		.3	(BK-0)	110				
15A-C	31	.4	(0-BK)	150				
19A-C	2001	.5	(BK-G)	19				
23A-C	12	.6	(G-BK)	23				
27A-C	13	.7	(BK-BR)	270				
31A-C	14	[L1	(BR-BK)	31				
32A-C	14	ACG1	(BK-S)	32	TERMINATE IN KSU			
35A-C	115	IL2	(S-BK)	35	ON BLOCK AND COLUMN			
36A-C	10	ACG2	(Y-BL)	36	FOR STATION CODE			
38A-C	16	ACG3	(BL-Y)	38	TERMINATED ON COLUMN			
39A-C	102	ACG4	(Y-O)	39	C OF 14A1-100			
40A-C	> 17	ACG5	(O-Y)	40	TERMINAL BLOCK			
420	143	IS	(Y-G)	42				
440	> 18	0	(G-Y)	44				
460	>44	SB	(Y-BR)	46				
470	19	10V	(BR-Y)	47	1.1			
490	45	ET	(Y-S)	49				
500	202	ER	(S-Y)	50				
3D-F	16	.1	(V-BL)	3				
7D-F	212	.2	(BL-V)	7				
11D-F	47	L3	(V-O)	11	TERMINATE IN KOU			
15D-F	22	_4	(0-V)	15	ON BLOCK AND COLUMN			
19D-F	48	15	(V-G)	19	FOR STATION CODE			
23D-F	23	L6	(G-V)	23	TERMINATED ON COLUMN			
27D-F	>49	17	(V-BR)	27	D OF 14A1-100			
31D-F	>24	IL1	(BR-V)	31	TERMINAL BLOCK			
32D-F		ACG1	(V-S)	32				
35D-F	>25	IL2	(S-V)	35	J			
0	$\rightarrow 25 \rightarrow$			0/				

Fig. 17-Connections for 14A1-100 Terminal Block (Sheet 3 of 4)

14A1-100 TERMINAL BLOCK CONNECTOR 4		CONNECTOR CABLE 4		KSU TERMINAL	
CONN. BLOCK TERMINAL		LEAD	COLOR		
3D-F	1	DESIG		1 .	
°70-F →	26>	10	(W-DL)	70	
• 11D-F >	1 >	13	(Ы-0)	110	
° 150-F →	27>	14	(0.4)	150	
o 19D−F →	2 >	15	(U-W)	100	A DE LE REAL PROPERTY AND
° 230-F →	28>	16	(G-U)	230	1
270-F	3 >	17	(U-RP)	270	21 22 22
°310-F →	29>		(PP_U)	210	
° 32D−F →	4 >	4001	(U-S)	320	TERMINATE IN KSU
0-35D-F	30>	TLO	(8-4)	250	ON BLOCK AND COLUMN
0 360-F →	5 >	1000	(0-W) (D-RL)	000	FUR STATION CODE
0 380-F →	31>	ACG2	(R-DL)	30	E OF 1441-100
° 390-F →	6 >	ACGA	(BL-R)	30	TERMINAL BLOCK
° 400-F →	32>	ACG5	(0-0)	100	TENTINE DECON
0 42F →	7 >	Ve	(B-G)	40	a company theme
O AAF	33>	00	(0-0)	42	the second second state
	8 >	CU CD	(0-R) (D. PD)	44	topies with an apart set
	34>	5D +10V	(R-DR)	40	realit have that a set of
	9 >	2100	(DR-R)	41	i al an and the set of the set
0 43C 50C	35>	EI	(R-5)	45	
0 20 5	10>	ER	(S-R)	50 0 /	and the second second
0 30-F	36>	LI	(BK-BL)	3 0	1
0 110 5	11>	12	(BL-BK)	110	Contraction and the second
0 150 5	37)	13	(BK-U)	11	such and they us
0 100 5	12)	L4	(U-BK)	100	or come and children
0 000 F	38>	10	(BK-G)	19	
0-230-F	13)	Lb	(G-BK)	23	LTV Createring 11
0 210 5	39)		(BK-BR)	21	town and the second
0 310-F	14)	1004	(BR-BK)	31	and added a month
0 320-F	40>	ACG1	(BK-S)	32	TERMINATE IN KSU
0-350-F	15)	112	(S-BK)	30	ON BLOCK AND COLUMN
0 300 5	41)	ACG2	(T-BL)	36	FOR STATION CODE
0 380-F	16)	ACG3	(BL-Y)	38	TERMINATED ON COLUMN
0 400 5	42)	AC64	(1-0)	39	F UF 14A1-100
0400-F	17)	ACG5	(U-Y)	40	TERMINAL BLUCK
0-42F	43)	VS	(1-6)	42	the second second
0-44F	18)	00	(G-Y)	44	terrare and the
0-475	44)	58	(T-BR)	40	
04/F	19)	± 10V	(BR-Y)	4/	
0-505	45)	EI	(1-5)	40	the second second
0 200 F	20)	ER	(5-1)	500	
0-000 F	46)	ACG2	(V-BL)	36 .	
0-000 F	21)	ACG3	(BL-V)	38	and a first same service of
0 400 F	47)	AUG4	(V-U)	39	TERMINATE IN KSU
400-1	22)	ACG5	(U-V)	40	ON BLOCK AND COLUMN
0-420	48	VS	(V-G)	42	FOR STATION CODE
0 440	23	CO	(G-V)	44	TERMINATED ON COLUMN
460	49	58	(V-BR)	46	D OF 14A1-100
4/U 0-400	24	±10V	(BR-V)	47	TERMINAL BLOCK
480	50	EI	(V-S)	49	Convinte Deve
0.000	25)	ER	(S-V)	50 ,	,

Fig. 17—Connections for 14A1-100 Terminal Block (Sheet 4 of 4)



PLACE CLIPS ON ROWS: 3, 7, 11, 15, 19, 23, 27, 31, 32, 35, 36, 38, 39, 40

Fig. 18—Position of B Bridging Clips on 14A1-100 Terminal Block

clamp (screw down) through the slot of the shelf, up into the base of the telephone set. Check that the pads on the telephone set base fit in the slots in the shelf and tighten the retaining clamp until the telephone set is held firmly in place.

> **Note:** It may be necessary to slightly bend the top slotted portion of the 833A adapter so that the headed rivets of the base pan align and seat properly.

3.19 Consoles: Up to three DSS or MW consoles, in any combination, can be used with a 7A Communication System. Consoles are usually associated with stations which are designated as attendant positions. Some systems will have only one attendant position; in such cases, either an MW or a DSS console or both can be located at the attendant position. If another station is designated as an alternate attendant position, a second or third console might be located there.

> **Note:** Terminations and power are provided in the 7A Communication System for either a DSS or MW selector console. If a second or third console is required, additional power and external terminations must be supplied.

4. FEATURES (IDENTIFICATION, OPERATION, CONNECTIONS, AND TESTING)

BASIC FEATURES

A. Automatic Button Restoration (ABR)

4.01 Automatic button restoration is a feature of the 832- and 2832-type telephone sets used with the 7A Communication System. When the handset is replaced, all depressed buttons return to the unoperated position. This prevents indvertent intrusion on calls in progress and insures that multiple buttons will not be left depressed on a set causing an undesired conference from the idle set.

4.02 The intercom-only telephone sets, 575AM and 2575AM, do not have ABR.

4.03 On 832- and 2832-type telephone sets equipped with a RECALL button, this feature should be used for flashing, instead of the switchhook. Otherwise, the ABR will release the line button when the switchhook is operated. On 832/2832A sets without recall, hold down the line button while flashing with the switchhook.

4.04 Automatic button restoration is a mechanical

function of the telephone set; no wiring is required and field adjustment of the mechanism is not recommended.

B. Common Audible

4.05 The 7A Communication System is factory-wired for the attendant station (intercom code 0) to receive tone ringing whenever there is an incoming call on any of the CO/PBX lines. (The lamp under the associated CO/PBX line button flashes for visual identification of the calling line.) See Fig. 22 for connections.

4.06 The attendant answers all incoming calls and either takes a message or forwards the call to the desired party using the intercom. To forward a call, the attendant puts the incoming call on hold (CO/PBX line lamp goes from steady to wink), then picks up an idle intercom path, dials the desired station, and voice signals that there is a call on a particular CO/PBX line. By observing the CO/PBX line lamp (going from wink to steady), the attendant is able to determine when the call is picked up. If after a suitable period of time the call is not picked up, the attendant may again pick up the line and proceed per local instructions.

4.07 Common audible is derived through diodes located on connecting block 1. As factory-wired,

there is one diode per CO/PBX line connected to a common audible terminal. A factory-provided strap (on the installer's side of block 1) connects the common audible terminal to station code 0.



Page 33

ISS 4, SECTION 518-450-100



Fig. 20—Installation of Wall Telephone Set



Fig. 21—Shelf for Wall Mounting COM KEY Telephone Set (D-180656 Kit of Parts)

4.08 To move the common audible signal to a station or stations other than, or in addition to, the attendant station (code 0), make the following changes on connecting block 1:

(1) Remove the factory-provided strap between terminals F9 and C1.

Up to ten stations, including the attendant, can be wired for common audible only if capacitor C1 is connected to fuse F12 as shown in Part E of Fig. 74. If it is not, only one station can have common audible.

(2) Run a strap from the common audible terminal F9 to the CO/PBX ring terminal (or terminals) in row C of the desired station (or stations) code. Use a continuous strap if more than one station code is connected to the common audible ring terminal.

4.09 To remove a particular CO/PBX line from the common audible group, remove the



Fig. 22-Connections for Common Audible

corresponding common audible diode from connecting block 1 (Fig. 22). When a CO/PBX is removed from the common audible ringing arrangement:

- The CO/PBX line must be connected to ring a selected station(s) via a CO ringing arrangement as described in paragraph 4.26
- The ringing cannot be transferred through the ring transfer arrangement.

C. Multiline Conferencing

4.10 Multiline conferencing is a feature of the telephone sets used in the system. Since there is no amplification involved, this type of conferencing is limited.

Note: Transmission levels will be reduced and transmission is not guaranteed.

4.11 Conferencing is accomplished by simultaneously depressing the CO/PBX line buttons of the CO/PBX lines to be conferenced.



Intercom and CO/PBX lines cannot be conferenced together.

4.12 All lines that are conferenced together may be put on hold simultaneously by depressing the HOLD button.

4.13 To make a call during a conference:

- (1) Depress HOLD button-all buttons restore.
- (2) Select an idle line.
- (3) Dial call.

(4) If it is desired to add this call to the conference while holding this CO/PBX line button down, depress the conferenced CO/PBX line buttons.

(5) To reenter conference again after call is completed, simultaneously depress conferenced buttons again.

4.14 If it is desired to add another call to the conference, while holding the conferenced CO/PBX line buttons down, depress button of CO/PBX line to be added.

4.15 To prevent dropping one of the participants when setting up a conference, ensure that the conferenced CO/PBX line buttons are held down when adding another station.

> Remember: The system may be disabled if multiple buttons are left depressed at an idle station after a conference.

4.16 Conferencing is a mechanical function of the telephone set and requires no wiring.

D. Pickup, Hold, and Illumination

4.17 The system provides pickup on CO/PBX and intercom lines and hold on CO/PBX lines. Lamps provide the following information: steady lamps are for line busy, flashing lamps for incoming calls, and winking lamps for hold.

4.18 The CO/PBX and intercom lines appear on the same buttons at all stations. By observing the lamps associated with the CO/PBX and intercom line buttons, the station user can readily determine the status of each line. Any station user can pick up any idle line or place any CO/PBX line on hold.

E. Tone and Voice Signaling

4.19 All stations are alerted to an incoming call by a distinctive tone signal. The CO/PBX ringing is a frequency-shifting tone. Intercom ringing is a single tone followed by voice signaling. Voice signaling is used in conjunction with tone signaling when calling a station on the intercom. When a station receives incoming CO/PBX tone signals and is simultaneously signaled on the intercom, the intercom signal is given preference.

F. 2-Path Intercom

4.20 The intercom has two separate talking paths.

A path is selected by depressing one of the two intercom buttons on the telephone set. There is no privacy on either path and any station may break into an existing conversation.

4.21 When it is desirable for a station to pick up only the two intercom lines and not have access to the CO/PBX lines, a 575AM or a 2575AM telephone set can be used. The 575AM and 2575AM telephone sets are connected to the 570-type KSU by A25B connector cables (Fig. 23).

4.22 The selector, used to select and alert the called stations, is shared between the two paths. The alerting signal at the called station is a tone burst followed by a voice signal from the calling station. The lamp signals on the intercom are as follows: When the selector has seized a path, the lamp associated with that path will flash on all telephone sets. This shows the called party which path to answer. When the called party answers, the flashing intercom lamp lights steadily. When an intercom path is idle, the associated lamp is off.

4.23 To place an intercom call:

- Select idle intercom path and depress associated button.
- (2) Lift telephone handset.

Note: If lamp is flashing on other intercom path, dialing cannot take place until the selector is released. While the selector is seized by another station, no dial tone or other indication is available.

- (3) Dial selected station—tone burst signals called station.
- (4) Calling station makes announcement or waits for called party to answer. When called party picks up, intercom lamp will go steady.


NOTES:

I. TERMINATE CONNECTOR CABLE FOR INTERCOM ONLY STATION

ON SAME BLOCK(S) AS ASSIGNED FOR FULL SERVICE STATION.

 ONLY LEADS SHOWN ARE REQUIRED. TERMINATE BALANCE OF CONN CABLE ON SAME COLUMN OF CONN BLOCK EXCEPT FOR 3RD IC PATH.

Fig. 23-Connections for Intercom-Only Telephone

SECTION 518-450-100

4.24 Intercom is factory-wired, requiring the 424C, 456B, and 460B KTUs. See Fig. 24 for KTU locations in the KSU. The intercom code of a station is determined by the column on connecting blocks 3, 4, or 5 on which the station cable is terminated. See paragraph 3.05(8) and Fig. 16.



Fig. 24—Location of 424C, 456B, and 460B KTUs, 2-Path Intercom

OPTIONAL FEATURES

A. CO Ringing

4.25 The CO ringing feature permits a station not wired for common audible to receive the ringing signal on a selected CO/PBX line. Any combination of stations may be connected for CO ringing on a one-line per-station basis.

Remember: The CO ringing is tone ringing.

4.26 A terminal representing each CO/PBX line is brought out on connecting block 1, row 21 (see Fig. 25). To connect CO ringing, on connecting block 1, column C, select the terminal associated with station to ring on a particular CO/PBX line. Then run a strap (RC-) from the station terminal in column C to the particular CO ring terminal in row 21. Figure 25 illustrates station 3 strapped (RC-1) to the CO ring terminal (in row 21) of CO/PBX line 1 and station 16 strapped (RC-2) to the CO ring terminal of CO/PBX line 2. In this instance, CO/PBX line 1 will ring at station 3 and the second CO/PBX line will ring at station 16.

B. External Signaling Circuit

4.27 Where external signaling devices (such as bells, gongs, chimes, lights or buzzers) are to be connected to the 7A Communication System, a 22A-49 apparatus unit must be provided. The 22A-49 apparatus unit is externally mounted and connections are made to the KSU with inside wire. Also, an external power supply must be provided to operate the signaling devices. The 22A-49 apparatus unit may be used to activate external signaling devices that are operated by an open circuit (through a relay break contact) or that are operated by a circuit closure (through a relay make contact).

Caution: The 22A-49 apparatus unit contains a nonadjustable, mercury-wetted, sealed contact relay and must be mounted in a vertical upright position.

- 4.28 The 22A-49 apparatus unit is used to activate external signaling devices that are connected for:
- tor:
- Station codes (see Fig. 26)
- · Common audible (see Fig. 27)
- CO/PBX ringing (see Fig. 27)
- Ring transfer (see Fig. 27).

4.29 One 22A-49 apparatus unit is required for each station code or each CO/PBX line equipped with an external signaling device. Connections for station codes are shown in Fig. 26. Connections for common audible, CO ringing and ring transfer are shown in Fig. 27. The maximum resistance of each lead between the KSU and the 22A-49 apparatus unit is 25 ohms.

 4.30 The KS-16301 type auxiliary signals or ringers are recommended as external signaling devices for use with the 7A Communication System.
 See Fig. 28 for connections. Refer to Section 463-110-100 for identification, installation, operation, maintenance, and ordering information on the KS-16301 type signals.

4.31 The external power supply used to operate the signaling devices must be properly fused and have the capacity to adequately power the signaling devices. The ac power receptacle should





meet requirements per paragraph 3.02. Information found in Section 167-416-201, 167-440-201, or 167-446-101 may be used as a guide toward selecting an appropriate power supply. Do not use a power supply that exceeds the contact rating of the 22A-49 apparatus unit.

C. Intercom Preset Conference

4.32 Intercom preset conference allows up to five preselected stations to be alerted simultaneously by dialing code 19.



Fig. 26—Station Code Connections for External Signaling Circuit (22A-49 Apparatus Unit)



Fig. 27—Common Audible, CO/PBX Ringing or Ring Transfer Connections for External Signaling Circuit (22A-49 Apparatus Unit)



Fig. 28-Connections for 22A-49 Apparatus Unit and KS-16301 Type Signals

4.33 When preset conference is used, station code 19 is forfeited. Signaling via preset conference takes precedence over CO/PBX ringing at a preset conference station.

4.34 To connect preset conference, strap the terminals in the preset conference row to the desired stations in column D, connecting block 1 (Fig. 29). For example, Fig. 29 shows that stations 5, 10, and 15 are wired for preset conference.

Note: Any intercom station may originate preset conference, but only those stations wired for preset conference will be alerted.

- 4.35 To use preset conference:
 - (1) Lift handset
 - (2) Select idle intercom path and depress associated button
 - (3) Dial 19-tone burst signals all stations wired for preset conference

Note: Attendant may use DSS code 19 if equipped with DSS console.

(4) Announcement is made to all preset conference stations simultaneously.

D. Music-On-Hold

4.36 The music-on-hold feature transmits music to calling or called parties on CO/PBX lines that are placed on hold.

4.37 Music-on-hold is provided on CO/PBX lines by a 451A or B KTU (with 400G or earlier KTUs in a 570A KSU), a 498A KTU equipped with a 116A1 CM (with any 400-type KTUs in a 570B KSU), a 33A voice coupler, and a customer-provided music source. The customer-provided music source must have an output impedance low enough to drive an 8-ohm load without distortion. The music source must also be adjustable so the listening level of the music-on-hold may be adjusted.

> Caution: The output of the CP music source must furnish ac coupling only—thus blocking all direct current to the input terminals of the 33A voice coupler.



The CP music source should be able to deliver up to one watt into an 8-ohm load. The 33A voice coupler will accept input from any customer-provided apparatus that does not blow the fuses in the voice coupler. If the customer wants a copy of the technical reference covering the 33A voice coupler, contact the local Telephone Company Business Office or the Marketing Representative. If a service call is caused by a malfunction of the customer-provided equipment, billing should be made in accordance with Section 660-101-312.

4.38 Make connections as follows:

- (a) If the KSU is a 570A (MD), plug the 451-type KTU into J18. If the KSU is a 570B, plug the 116A1 CM into J1/J2 on the 498A KTU and then plug the 498A into J18 on the KSU. See Fig. 30 for KTU location.
- (b) Install 33A voice coupler (Fig. 9) as follows:
 - (1) Remove cover from voice coupler
 - (2) Mount voice coupler externally to KSU (wherever customer desires)
 - (3) Connect voice coupler to KSU as shown in Fig. 31
 - (4) Have customer connect voice coupler to his music source as shown in Fig. 31.

Caution: Ensure that 35P fuses are installed with the spring at the bottom. If fuses are improperly installed, blown fuses may cause damage to customer's amplifier.

- (5) Replace cover on voice coupler.
- (c) Adjustment procedures for music-on-hold is as follows:
 - (1) Turn potentiometer on 33A voice coupler to full counterclockwise position
 - (2) Place call to a 7A station



Fig. 29—Connections for Intercom Preset Conference

- (3) Answer call and place it on hold
- (4) Have customer adjust his music source for a comfortable listening level at the held station
- (5) Disconnect call.

E. Ring Transfer

4.39 Ring transfer switches the incoming CO/PBX ringing from the attendant station (code 0) to an alternate telephone or telephones in the 7A Communication System. Ring transfer can be wired for fixed station or as a flexible station arrangement. With fixed station ring transfer, incoming CO/PBX calls are transferred to a specific station or group



Fig. 30-Location of Music-On-Hold Circuit



INSIDE WIRE (PROVIDE LOCALLY)

Fig. 31-Connections for 33A Voice Coupler

of stations as fixed by an option strap in the KSU. The flexible station ring transfer arrangement utilizes a 6041G key to permit any one of up to five stations or groups of stations to be selected for ring transfer of incoming CO/PBX calls.

4.40 To operate ring transfer wired for fixed station transfer, depress RING TR button on attendant telephone set (locking it down). To transfer ringing back to the attendant station, depress RING TR button again (which releases it). While the button is depressed, the lamp under it is lit (steady).

4.41 To operate ring transfer arrangement for flexible station transfer, depress button on the 6041G key associated with the station or stations to receive incoming CO/PBX calls. Then depress RING TR button on the attendant telephone set (locking it down). While the button on the attendant set is depressed, the lamp under it is lit (steady). To transfer ringing back to the attendant station, depress the RING TR button again (which releases it). Afterward, operate the release button on the 6041G key.

4.42 The attendant telephone set must be equipped with a ring transfer button to control ring transfer. Where the 832/2832C, CM or EM telephone set is installed as an attendant station, the factory-provided RING TR button must be wired in. See Fig. 32 for connections. Where the 832A or 2832A telephone set is installed as an attendant station, a D-180487 Kit of Parts must be added to the telephone set as follows:

- (1) Remove faceplate
- (2) Pry apparatus blank off locating pins (located below and to the right edge of key strip)
- (3) Press ring transfer button (651C key) on locating pins
- (4) Connect leads according to Fig. 32
- (5) Install designation strip in key cap
- (6) Replace faceplate.

4.43 For fixed station ring transfer, in the KSU, run a strap from the RT terminal (column F, terminal 24) on connecting block 1 to the station code or station codes (column C, connecting block 1) selected for ring transfer. For example, Fig. 32 shows station 12 wired for ring transfer. When more than one station code is connected to the RT terminal, run a continuous strap to all stations (ten maximum) selected for ring transfer.

4.44 For flexible station ring transfer:

(1) Install a 6041G key at the attendant station

- (2) Provide three cable pairs or six 24-gauge conductors between the 6041G key and the KSU
- (3) Connect one conductor (common lead) to terminal M of the 6041G key and strap terminals M and X together (see Fig. 32 or 33)
- (4) Terminate the remaining five conductors on terminals 1H, 2H, 3H, 4H, and 5H of the 6041G key
- (5) At the KSU, terminate one conductor (common lead) on the RT terminal (column F, terminal 24) of connecting block 1
- (6) Terminate the remaining five conductors on the terminals of connecting block 1, column C, corresponding to the codes of the stations selected for ring transfer (see Fig. 32)
- (7) Install designation strip on 6041G key— Designate the first button (position A) as RELEASE and label the remaining buttons according to the stations they connect for ring transfer.

F. Paging and Background Music

- 4.45 In the 7A Communication System, paging may be:
 - (a) Provided for up to seven speakers, using indoor or outdoor speakers
 - (b) Connected to a COAM paging system
 - (c) Connected to a separate paging system provided by the telephone company.
- 4.46 For background music, a 33A voice coupler must be installed and connected to the KSU and customer-provided music source according to paragraph 4.38(b). When the paging system is not being used, the customer-provided music source may be used to provide background music over the paging speakers.

4.47 A paging system should be loud enough to be heard but not loud enough to annoy those who work near the speakers. The number and location of speakers are influenced mainly by the environment in which they will be located. Figure 34 shows several examples of speaker placement. It may be necessary to experiment with speaker placement on site to achieve the desired results. Noisy locations may require additional speakers or an auxiliary paging system. Refer to Section 981-251-100 for general information on loudspeaker paging system.

> Caution: Avoid placing loudspeakers directly in front of or close to stations that will utilize the paging system. An undesirable oscillation (squeal) can result from such speaker placement. A minimum separation of 60 feet between telephone sets and loudspeakers is recommended. The problem can also be reduced by using a 456B voice and tone alerting circuit KTU instead of a 456A.

- **4.48** The system is factory-wired so paging may be activated by dialing code 2.
- 4.49 Make connections as follows.
 - Install 457C KTU in J15. See Fig. 35 for KTU location.
 - (2) If background music is provided, install the 33A voice coupler according to paragraph 4.38(b).

(3) Connect paging speakers as shown in Fig. 36. Speaker wiring should be run separately and not a part of a voice cable. Quad inside wire should be used with both pairs connected. (Where it may become necessary to "stack" wires on the connecting block terminals, use 183B2 adapters.) Speakers connected in this manner can be located a maximum of 320 feet from the KSU. Indoor speakers should be hung as close to the ceiling as possible.

Note: If the customer does not have music-on-hold but does have background music, turn the potentiometer in the 33A voice coupler fully clockwise. Have customer adjust his music level.

4.50 The KS-21880L1 loudspeaker (Fig. 10) is an indoor speaker. It is wall-mounted or may be mounted over an outlet box. A mounting clip is furnished with the speaker. To mount speaker (see Fig. 10), screw mounting clip to wall or outlet box, slip speaker baffle over mounting clip and

TELEPHONE SET CONNECTIONS FOR RING TRANSFER.

- D-180487 KIT OF PARTS REQUIRED FOR 832A AND 2832A TEL SETS.
- CONNECTIONS ONLY FOR 832C AND



ANY ONE OF UP TO FIVE STATIONS MAY BE SELECTED FOR RING TRANSFER THROUGH 6041G KEY

Fig. 32-Connections for Ring Transfer

pull speaker down until it is firmly held by the mounting clip. Speaker volume is controlled by a potentiometer (with screwdriver adjustment slot) located in the bottom of the speaker. Adjust speaker volume after speaker is mounted.

Speaker volume level will be affected by changes in room content. The addition of furniture, fixtures, draperies, carpeting or wall covering may necessitate increasing speaker volume, which, however, may increase the tendency

of the system to "squeal" because of feedback between loudspeakers and telephones. If this occurs, try to change the relative positions of loudspeakers and telephones, if possible. If a 456A voice and tone alerting circuit is used, replace it with a 456B.

4.51 The KS-21939L2 loudspeaker (Fig. 11) is applicable to locations with adverse weather conditions. The loudspeaker is equipped with a

SECTION 518-450-100



NOTE :

1. ANY STATION MAY BE SELECTED FOR RING TRANSFER.

TRANSFER TO STATION 3, 4, 5, 9 OR 10 IS SHOWN HERE. 2. DOTTED LINES INDICATE FACTORY WIRING IN KSU.

Fig. 33—Example of Connections for Flexible Station Ring Transfer Arrangement



EXAMPLE A - SPEAKERS LOCATED ON ONE WALL OF ROOM (NOTES 1, 2 AND 3)



EXAMPLE B - SPEAKERS LOCATED ON OPPOSITE WALLS OF ROOM (NOTES I AND 2)



EXAMPLE C - SPEAKERS LOCATED IN INDIVIDUAL ROOMS (NOTES 1, 2 AND 4)



Fig. 34-Example of Paging Speaker Location



Fig. 35-Location of 457C KTU, Paging Amplifier

NOTES:

- EXAMPLES A, B AND C ARE FOR QUIET OR OFFICE TYPE ENVIRONMENTS, LESS THAN 650B SOUND PRESSURE LEVEL (SPL). ALL SPEAKERS SHOULD BE LOCATED AT LEAST 18.3 METERS (60 FEET) FROM ANY STATION USED FOR PAGING.
- 2. SPEAKER HIRING SHOULD BE RUN SEPARATELY, NOT PART OF A VOICE CABLE, QUAD CABLE, SHOULD BE USED HITH BOTH PAIRS CONNECTED. SPEAKERS SHOULD BE HUNG AS CLOSE TO THE CEILING AS POSSIBLE. MAXIMUM SPEAKER DISTANCE FROM THE KSU IS 97.6M (320 FT.) USING QUAD HIRE.
- SPEAKERS REACH A DEPTH OF 9.1M (30 FT.). IF ROOM IS OVER 9.1M (30 FT.) WIDE, FACING SPEAKERS SHOULD BE USED.
- 4. ONE SPEAKER WILL SERVE A ROOM UP TO 7.6M BY 7.6M (25.BY 25 FT.)
- 5. ONE SPEAKER (HORN) MOUNTED 6.1M (20 FT.) ABOVE GROUND LEVEL WILL COVER AN AREA APPROXIMATELY 24.4 BY 30.5M (80 BY 100 FT.). IF THE HORN IS MOUNTED LESS THAN 6.1M (20 FT.) ABOVE GROUND LEVEL, TWO HORNS MUST BE USED, HORNS SHOULD NOT BE MOUNTED LESS THAN 4.6M (15 FT.) ABOVE GROUND LEVEL, IF MORE THAN ONE HORN IS USED, THEY SHOULD BE MOUNTED VERTICALLY, RATHER THAN SIDE-BY-SIDE.

swivel mounting bracket for mounting on a flat surface. Also the speaker can be fastened to a 1/2-inch pipe or conduit. The loudspeaker is equipped with a screwdriver adjusted volume control. Screw terminals are provided for connections to the speaker.



When using outdoor speakers, the speaker leads must be protected in accordance with local instructions or Section 460-100-400.



Fig. 36—Connections for Paging Speakers (or 20A-49 Apparatus Unit)

4.52 Alignment procedure for paging and background music is as follows:

 Dial paging code and adjust potentiometer on each speaker for proper volume while paging in a normal voice

(2) Disconnect

 (3) Have customer adjust potentiometer on voice coupler for desired level of background music over paging system

(4) Inform customer after alignment is complete that if the gain of the music source is readjusted, the background music and music-on-hold will be affected.

Note: If the customer has paging and music-on-hold but does not want background music, the potentiometer on the voice coupler should remain in the counterclockwise position.

4.53 A COAM paging system or a separate telephone company-provided paging system is connected to the 7A Communication System through a 20A-49 apparatus unit (see Fig. 37). The 20A-49 apparatus unit is mounted externally to the KSU.

(a) Connect the 20A-49 apparatus unit as follows.

(1) Remove cover from the 20A-49 apparatus unit.

(2) Mount the 20A-49 apparatus unit within 200 feet of KSU (wherever customer desires).

- (3) Connect the apparatus unit to the KSU as shown in Fig. 37. Wiring should be run separately and not be a part of the voice cable.
- (4) Have customer connect paging system to apparatus unit, using shielded wire, as shown in Fig. 37.
- (5) Replace cover on apparatus unit.
- (b) Adjustment procedure for the 20A-49 apparatus unit is as follows:
 - (1) Turn potentiometer to full counterclockwise position
 - (2) Select an idle intercom path and dial 2 (paging code)

(3) Using normal voice level, make test announcement while turning potentiometer clockwise until suitable voice level for COAM equipment is reached

Note: Where the COAM paging equipment has full control of the paging volume, turn the potentiometer of the 20A-49 apparatus unit to the full clockwise position.



The 20A-49 apparatus unit provides a nominal 300-ohm output to a customer-owned paging system (Fig. 37). It does not provide a means to activate the customer's equipment; therefore, the customer's equipment must be in the ON mode at all times.

(4) Disconnect call.



If a service call is caused by a malfunction of the customer-provided equipment, billing should be made in accordance with Section 660-101-312.

G. Power Failure Ringer

4.54 For each location to be equipped with power failure transfer, a power failure ringer (E1C) must be installed. Install the E1C ringer near telephone set location. See Fig. 38 for connections.

H. Power Failure Transfer

4.55 Utilizing a 452A KTU and externally mounted E1C ringers, this feature provides an audible indication of incoming CO/PBX calls during a power failure condition.

4.56 The tip and ring of all CO/PBX lines are wired to line ringers through normally made contacts of relays in the 452A KTU. The relays are held operated while local power is available. When power is lost to the KSU, the relays release and the tip and ring of the CO/PBX lines are cut through to the line ringers.

4.57 The tip and ring from each CO/PBX line is brought out on connecting block 1 (Fig. 38). The tip and ring of the desired CO/PBX line may be strapped to the V-S and S-V pair of the desired station by connections as shown in Fig. 38. In this instance, the tip and ring of the first CO/PBX line is strapped to the V-S and S-V pair of station 3. This puts line ringing at station 3 if power failure should occur. The tip and ring may also be connected between the KSU and the external ringer by an auxiliary cable.

4.58 Install 452A KTU in J1. See Fig. 39 for KTU location.

I. Privacy

4.59 Privacy prevents a station from bridging into a CO/PBX call in progress. Privacy is a station feature, and each station that is to be excluded (locked out) must be equipped with a privacy circuit board.

4.60 A privacy circuit, D-180486 Kit of Parts, must be added to an 832/2832A (MD), B (MD), BM, or DM telephone set used as a privacy station. The 832/2832C (MD), CM, and EM telephone sets are wired at the factory with the privacy circuit operational.

4.61 The privacy circuit operates only when the telephone set is off-hook. The circuit monitors the A lead to determine the status of the line. A ground (or positive potential) on the A lead indicates the line is busy, operates the privacy circuit, and the station attempting to bridge is excluded. A negative potential on the A lead does not cause the privacy circuit to operate and the set is not excluded. There is no privacy on the intercom paths.

- 4.62 Mount the D-180486 Kit of Parts (privacy circuit) as follows.
 - (1) Remove faceplate.
 - (2) Mount privacy circuit board on the two standoffs located at the left front of the telephone set base (Fig. 40).
 - (3) Fasten privacy circuit board to standoffs using mounting screws furnished with the telephone set.
 - (4) Connect leads according to Table E.
 - (5) To test privacy circuit:
 - (a) At a station other than the one being tested, lift handset and depress a CO/PBX line button
 - (b) At station being tested, lift handset and depress CO/PBX line button on same line; no side tone should be heard
 - (c) Repeat test on all CO/PBX lines
 - (d) Test all sets equipped with a privacy circuit.
- **4.63** To change a privacy station to a nonprivacy station, disable the privacy circuit according to Table F or G.

SECTION 518-450-100



* FACTORY PROVIDED DIODE



J. **Privacy Release**

4.64 Privacy release permits a second privacy-equipped (locked out) telephone to be bridged into a call on a CO/PBX line.

4.65 A privacy release button, D-180488 Kit of Parts, must be added to an 832A or 2832A telephone set for privacy release. Refer to Table D for a summary of sets which are factory-equipped with the privacy release feature.

When a station is off-hook with a CO/PBX 4.66 line button depressed, any station equipped with a privacy circuit will be locked out from that CO/PBX line. To permit a privacy-equipped station to bridge into a call:

- (1) Depress (and hold down) the PRIV RLS button at the station where the CO/PBX line is picked up
- (2) Observe that line lamp changes from steady to wink (the line goes on hold)

The privacy-equipped station may now bridge into the call.

(3) Observe that line lamp changes from wink to steady (indicating station has entered the call)



REPRESENT THE 7 INCOMING CO/PBX LINE NUMBERS ARE FOR REFERENCE ONLY AND DO NOT APPEAR ON THE BLOCK. + CONNECTIONS AS SHOWN PUTS POWER FAILURE IN THE STATION CABLE FOR STATION 3 A GIVEN STATION MAY

PICK UP ONLY ONE POWER FAILURE LINE.

USE INSIDE WIRE FOR RINGER CONNECTIONS.

1	FROM TEL SET TERMINAL	TO RINGER TERMINAL	LEAD DESIGNATION
	20	5	ER
9	21	6	ET
2	FROM A25B CABLE CONNECTOR (USING ADAPTER)	TO RINGER TERMINAL	LEAD DESIGNATION
	PIN 25	5	ER
9	PIN 50	6	ET
3	FROM CONN BLK 3, 4 OR 5 IN KSU	TO RINGER TERMINAL	LEAD DESIGNATION
	TERM 50	5	ER-
9	TERM 49	6	ET-

CONNECT POWER FAILURE RINGER (EIC) BY ONE OF THE FOLLOWING METHODS:

Fig. 38-Connections for Power Failure Transfer

(4) Release the PRIV RLS button.

To allow an additional privacy-equipped station 4.67 to bridge into the call, both stations must depress their PRIV RLS buttons simultaneously. The line lamp will change from steady to wink. As the third station bridges into the call, the line

lamp will become steady. The PRIV RLS buttons are then released.

4.68 The D-180488 Kit of Parts (privacy release button) is mounted in the 832A or 2832A

telephone set and connected as follows:

(a) Remove faceplate



Fig. 39—Location of 452A KTU, Power Failure Transfer



Fig. 40—Privacy Circuit Mounted in Telephone Set

Page 54

- (2) Pry apparatus blank off locating pins (located below and to the right edge of key strip)
- (3) Press privacy release button (651D key) on locating pins
- (4) Connect leads according to Table H
- (5) Install designation strip in key cap.
- 4.69 Where privacy release is no longer required, the privacy release button may be disabled. See Table I or J for connections.

K. Recall

4.70 Recall provides the same functions as switchhook flash without restoring the line buttons. Recall is accomplished by depressing the RECALL button on the telephone set. The RECALL button is designated with an amber cap.

Caution: If CO/PBX lines are conferenced and the RECALL button is depressed, the conferenced lines may be disconnected.

4.71 A recall button, D-180591 Kit of Parts, must be added to an 832A or 2832A telephone set

if this feature is required. All other 832- and 2832-type telephone sets are factory-equipped with a RECALL button.

4.72 The D-180591 Kit of Parts (recall button) is mounted in the 832A or 2832A telephone set and connected as follows:

- (1) Remove faceplate
- (2) Pry apparatus blank off locating pins (located below and to the right edge of key strip)
- (3) Press recall button (651F key) on locating pins
- (4) Connect leads according to Table K
- (5) Install designation strip in key cap and install amber key cap on RECALL button.

4.73 The 832A and 2832A telephone sets equipped with RECALL buttons are electrically equivalent to the 832/2832B, BM, and DM telephone sets.

	-		-
TΔ	RI	E.	E.
10	~		

		MOVE	EAD	
COLOR	CONNECT LEAD TO TEL SET TERMINAL	FROM TEL SET TERMINAL	TO PRIV BOARD TERMINAL	
0*	8			
BR*	F on Network			
S*	15‡			
BK*	12			
BL*	6			
R†		13	P2	
G-W†		13	P1	
Y†		6	R1	
0†		F on Network	Т	

832/2832A, B, BM, AND DM TELEPHONE SET CONNECTIONS FOR PRIVACY CIRCUIT (D-180486 KIT OF PARTS)

* Privacy board leads.

† Tel set leads.

‡ Store slate lead under screw terminal S2 when privacy release is provided (832A/2832A only).

L. Speakerphone

4.74 Normal speakerphone service may be provided at all stations in the system. Connect speakerphone as follows:



When installing a 3B or 4A speakerphone in conjunction with a modular 832or 2832-type telephone set, determine if there is an orange (O) lead on terminal 27 of the telephone set terminal board. If there is, move it to terminal 22. Failure to move this lead will cause the telephone set dial to be inoperative when the speakerphone is in use.

3B Speakerphone

4.75 Connect the D10R cord between the telephone set and 55B control unit. Connect the 666B transmitter, 760A loudspeaker, and 2012B transformer to the 55B control unit. See Table L for connections. Plug 2012B transformer into ac receptacle. (Refer to Section 512-620-487 for illustrations and additional information on 3B speakerphone connections.)

4A Speakerphone

4.76 Install 223A adapter within cord length (7 feet) of telephone set. Connect M16C cord to telephone set as shown in Table M. Plug loudspeaker, transmitter, and power cords into 223A adapter. Plug 85B1 power unit into ac receptacle. (Refer to Section 512-740-471 for

TABLE F

	DISCONNECT LEAD	MOVE LI	EAD	
COLOR	FROM TEL SET TERMINAL	FROM PRIVACY BOARD TERMINAL	TO TEL SET TERMINAL	
0*	8			
BR*	F on Network		1.1	
S*	15‡			
BK*	12			
BL*	6			
R†		P2	13	
G-W†		P1	13	
Y†		R1	6	
0†		Т	F on Network	

832/2832A, B, BM, AND DM TELEPHONE SET CONNECTIONS TO REMOVE PRIVACY CIRCUIT

* Privacy board leads.

† Tel set leads.

‡ Remove slate lead from under screw terminal S2 when privacy release is provided (832A/2832A only).

TABLE G

ALL 832/2832-TYPE TELEPHONE SET CONNECTIONS TO DISABLE PRIVACY CIRCUIT

	MOVE LEAD IN TEL SET				
COLOR	FROM TERM.	TO TERM.			
0	8	*			
BK	12	*			

* Insulate and store.

illustrations and additional information on 4A speakerphone connections.)

Note: Speakerphone does not prevent normal use of the telephone set for originating, receiving, or transferring calls.

- 4.77 To originate a call using speakerphone:
 - (1) Depress CO/PBX or intercom button associated with an idle line.

(2) Momentarily depress transmitter ON button. ON lamp lights and dial tone is heard through the loudspeaker.

(3) Dial number in normal manner.

(4) When called party answers, transmitter and loudspeaker are used to carry on the conversation. Adjust volume level as desired.

- 4.78 To answer an incoming call using speakerphone:
 - When audible tone signals an incoming call, depress CO/PBX or intercom button associated with flashing lamp.

TABLE H

832A AND 2832A TELEPHONE SET CONNECTIONS FOR PRIVACY RELEASE BUTTON (D-180488 KIT OF PARTS)

TEL SET LEAD	PRIVACY BOARD LEAD	PRIVACY RELEASE KEY LEADS	MOVE LEADS FROM TEL SET TERM.	CONNECT TO TEL SET TERM.	MOVE LEADS TO PRIVACY BOARD TERM.
	in the	O-BK		10	1000
	million	BK-BL		15	
	and	G-Y		27	
	in the mired	Y-G	1.0	27	
	the states of	G-W		2*	S2†
BK			15	2*	S2†
	S†		15		S2

* If telephone set does not have privacy circuit.

† If telephone set has privacy circuit and privacy release is now being added.

TABLE I

TEL CET	PRIVACY	PRIVACY	Y REMOVE	MOVE LEADS	
LEAD	BOARD LEAD	BUTTON	TEL SET TERM.	FROM PRIVACY BOARD TERM.	TO TEL SET TERM.
		O-BK	10		
CO DE ORIO		BK-BL	15		
		G-Y	27	and and a state	averant sta
1 18-12	A TABLE CAR	Y-G	27		S and an are
		G-W	2*	S2	
BK	THE THE		2*	S2	15
-	S†	Constantia		S2	15

832A AND 2832A TELEPHONE SET CONNECTIONS TO REMOVE PRIVACY RELEASE BUTTON

* If telephone set does not have privacy circuit.

† If telephone set has privacy circuit and privacy release is being removed.

TABLE J

ALL 832/2832-TYPE TELEPHONE SET CONNECTIONS TO DISABLE PRIVACY RELEASE BUTTON

COLOR	MOVE LEAD IN TEL SET			
COLOR	FROM TERM.	TO TERM.		
O-BK	10	15		

TABLE K

832A AND 2832A TELEPHONE SET CONNECTIONS FOR RECALL BUTTON (D-180591 KIT OF PARTS)

651F KEY	CONNECT TO				
LEAD COLOR	TERMINAL BOARD	NETWORK			
W		GN			
W		R			
Y	4				
Y	6				

Note: Remove Y strap from 4 and 6 on telephone set terminal board.

- (2) Momentarily depress transmitter ON button. Audible signal is silenced and the speakerphone is connected to the line.
- (3) Answer call using transmitter and loudspeaker to carry on conversation.
- **4.79** To disable transmitter when it is desired not to transmit conversation from the surrounding area to the distant station:
 - Depress transmitter ON button during entire period transmitter is to be disabled.

Note: With transmitter disabled, conversation will not be transmitted to the distant station; however, the distant party may be heard over the loudspeaker.

- (2) Release transmitter ON button and system is restored to hands-free operation.
- 4.80 To transfer from handset to speakerphone operation:
 - (1) Put line on hold
 - (2) Hang up handset
 - (3) Turn speakerphone on
 - (4) Depress line button.
- 4.81 To transfer from speakerphone to handset operation, lift handset during speakerphone

operation to automatically transfer to handset operation. When it is necessary to transfer back to speakerphone, refer to paragraph 4.80 to prevent disconnect.

4.82 To terminate a call on speakerphone, momentarily depress transmitter OFF button.

Note: Restore depressed line buttons after a conference call.

M. Station Busy Consoles

4.83 The 570-type KSU has the capacity for one station busy console—either DSS or MW. However, a maximum of three consoles can be connected to a COM KEY 718 System (refer to N. Multiple Consoles). If one DSS console is to be connected, terminate the A25B connector cable on column E of block 3 (Fig. 41). If one MW console is to be connected, terminate the cable on column D of block 3 (Fig. 42). Schematics of the 6A1 and 6B1 consoles are provided at the end of the section (Fig. 87 and 88).



If any DSS consoles are to be installed, be sure that the D0-D1 and CG0-CG1 straps on connecting block 3 are removed (see connection diagrams). If no DSS consoles are installed, be sure that straps are in place.

Station Busy Console (6A1) With DSS

4.84 By first selecting an idle intercom path, then

depressing the appropriate button on the 6A1 console, an attendant may signal any station over the intercom or make announcements over

-		-		-	
т	n	R		-	
	~	D	•	-	•

3B SPEAKERPHONE CONNECTIONS

	CONNECT L	EADS FROM	THE PLAN	A LONG	C	DRD COLOR	S	CONNECT LEADS TO 55B
TEL SET TERM.	TRMTR TERM.	SPEAKER TERM.	TRNSF TERM.	LEAD DESIG	DIOR	T7A	R2FK	CONTROL UNIT TERM. ‡
94				P4*	WC			13
24				IR†	W-5			6
20	-			P3*	C W			4
30				IT†	5-11			15
25†	1			T1	WRI			1
RR§*		- 1		11	W-DL			1
6				R1	BL-W			10
29				LK	W-BR			35
8				AG	BR-W			11
10				A1	W-G	10 - 11		2
19¶					O-W			32
**					W-O			23
	8			LK	-	BK-O		35
	7			F1		G-Y		17
	5			S		O-BK		18
	6			A1		Y-0		19
	3			M2		BK-S		16
	2		-	P1		BL-R		8
	1			M1		S-BK		7
		++		SP2	10		G	20
		++		SP1			R	29§§
	1		‡‡	TF1			-	27
	1.7 11411		‡ ‡	TF2				36

Note: On modular sets, move orange lead from terminal 27 on tel set terminal board to terminal 22.

* For rotary dial tel set.

† For TOUCH-TONE tel set.

‡ Strap terminals 4 and 5 on control unit when used with TOUCH-TONE tel sets.

§ Located on network.

¶ Also remove W-S lead from tel set amplifier terminal 1 and connect it to terminal 19.

** Connect W-O lead to terminal 1 on tel set amplifier.

†† Speaker terminals are not designated.

‡‡ Use inside wire.

§§ Connect lead to terminal 30 if a reduction in volume is desired.

M16C 0	ORD	TELEPHONE SET	TERMINAL	
LEAD COLOR	LEAD DESIG	832-TYPE	2832-TYPE	
W-BR	A1	10	10	
W-O	AG	8	8	
BL-W	R1	6	6	
W-BL	T1	RR (Network)	25	
G-W	P4	24		
GI	IR		24	
WC	P3	30		
in o	IT		30	
O-W	LK	29	29	

TABLE M

4A SPEAKERPHONE CONNECTIONS

Note: To reduce the volume of voice signaling or ringing while on speakerphone, make the following changes:

- Remove W-S from terminal 1 of telephone set amplifier and connect to S-W of M16C cord using spare terminal or D-161488 connector.
- (2) Connect BL-R of M16C cord to amplifier terminal 1.
- (3) On modular sets, move orange lead from terminal 27 on tel set terminal board to terminal 22.

the paging system. The console also provides the attendant with a visual indication of a busy station. Seventeen buttons on the console correspond to the station codes (codes 3 through 19); one button is associated with paging, one button is arranged for recall, and one button is spare. See Fig. 87 for schematic of 6A1 selector console.

4.85 Any station having the handset off-hook lights a lamp under the associated button on the 6A1/DSS console as a visual indication of a busy station. The operated switchhook contacts of a telephone set extend ground over an SB() lead, through the KSU to the 6A1 console, thus lighting the lamp under the associated button in the DSS field.

4.86 To DSS from the 6A1 console:

(1) Lift handset on the associated telephone set.

- Select idle intercom path and depress intercom button.
- (3) On the 6A1 console, momentarily depress button on DSS field corresponding to desired station-tone burst signals called station.
- (4) Announcement may now be made to called party.
- **4.87** If called party may be reached at another station, proceed as follows:
 - Momentarily depress RECALL button on DSS console—dial tone will be returned.
 - (2) Momentarily depress button on DSS field corresponding to desired station—tone burst signals called party.
 - (3) Announcement may now be made to called party.

ISS 4, SECTION 518-450-100

A258 CONN CABLE

Image: Non-State of the state of t		COLOR	LEAD DESIG	-	-
TO BL-W) SB2 O O-OI (W-O) SB3 O O-O O (W-O) SB3 O O-O O (W-G) SB4 O O-O O (W-G) SB5 O O-O O (W-G) SB5 O O-O O (W-G) SB1 O O-O O (W-S) SB9 O O-O O (BR-W) SB10 O O-O O (R-BL) SB11 O O-O O (R-BL) SB14 O O-O O (R-R) SB18 O O-O O (R-R) SB18 O O-O O (R-BL) 18V± O O-O O (R-BR) SB19 O O-O O (BR-R) BV± O O-O O (S-S) SB19 O	ſ	(V-BL)	SRI	EF	GH
Image: construction of the second s		(81-4)	882	-0	0-01
IO IO<		(W-0)	SR3	0	0-0
Image: Construction of the second s		(0-W)	SRA	-0	0-0
Image: construction of the second s		(W-G)	585	10	0-0
Image: construction of the second s		(G-W)	SR6	0	0-05
TO SB1 O		(W-BR)	SB7	-0	0-0
Image: second		(BR-W)	SRR	-0	0-0
TO (S-W) SB10 O O O (R-BL) SB11 O O O O O (BL-R) SB12 O O O O O O (R-O) SB13 O <		(W-S)	SB9	-0	0-0
TO (R-BL) SB11 O O O (R-BL) SB12 O O O O O (R-BL) SB12 O </td <td></td> <td>(S-W)</td> <td>SBIO</td> <td>-0</td> <td>0-0</td>		(S-W)	SBIO	-0	0-0
Image: Construction of the second s		(R-BI)	SBLL	-0	0-010
ID ID <thid< th=""> ID ID ID<!--</td--><td></td><td>(BI-R)</td><td>SB12</td><td>-0</td><td>0-0</td></thid<>		(BI-R)	SB12	-0	0-0
TO (0-R) SB14 0 0-0 (R-G) SB15 0 0-018 (R-R) SB16 0 0-018 (R-R) SB16 0 0-018 (R-BR) SB17 0 0-0 (R-BR) SB18 0 0-0 (R-BR) SB18 0 0-0 (BR-R) SB18 0 0-0 (BR-BL) 18V± 0 0-0 (BR-BK) 18V± 0 0-0 (BR-BK) BV± 0 0-0 (BR-BK) B GRD 0 0-0 (BR-BK) B GRD 0 0-0 (BR-S) B GRD 0 0-0 (BR-S) B GRD 0 0-0 (BR-S) B GRD 0 0-0 (Y-B) TTG 0 0-0 (Y-B) TTG 0 0-0 (Y-B) TTG 0 0 (Y-B)		(R-0)	SB13	-0	0-0
IO IO<		(0-P)	SBIA	0	0-0
IO IO IO IOO IOO <thioo< th=""> <thioo< th=""> <thioo< th=""></thioo<></thioo<></thioo<>		(P-G)	SBIS	-0	0-0
TO (R-BR) SB17 0		(G-R)	SBIG	10	0-015
IN IN<		(P-BD)	\$917	-0	0-0
IDA-RY Joins O		(80-0)	5017	-0	0-0
TO Solig O <td></td> <td>(0-6)</td> <td>5010</td> <td>-0</td> <td>0-0</td>		(0-6)	5010	-0	0-0
TO (3*A) 16*2 0 -02 (BL-BK) 18*2 0 0 0 (BK-O) 18*2 0 0 0 (BK-G) 18*2 0 0 0 (B-BK) 18*2 0 0 0 0 (B-BK) 18*2 0 0 0 0 0 (B-BK) 18*2 0		(9-D)	1014	-0	0-0
ID ID<		(BK-BI)	1074	10	0-02
TO 161-70/1 1671 0 <t< td=""><td></td><td>(QK-DL)</td><td>1074</td><td>-0</td><td>0-0</td></t<>		(QK-DL)	1074	-0	0-0
TO GR-0 To VI O O O STATION BUSY CONSOLE GR-6) 18V± O		(BK-O)	1014	10	0-0
TO STATION BUSY CONSOLE CO-WA (G-BK) TO DO CO-OC (BK-G) 18V± O O-OC (BK-BR) D0 O O-OC (BK-BR) D1 O+ O-OC (BK-BR) B GRD O-OC (BK-BR) B GRD O-OC (BK-S) B GRD O-OC (BK-S) B GRD O-OC (BR-SK) B GRD O-OC (Y-BL) B GRD O-OC (Y-BL) B GRD O-OC (Y-G) TTG O-OC O-OC (Y-G) TTG O-OC O-OC (Y-BL) CGO O+Y O-OC (V-C) Y2 O O-OC		(0-9K)	1014	-0	0-0
TO STATION BUSY CONSOLE CAN'S (BK-BR) DI DI O		(0-0K)	1074	-0	0-0
STATION BUSY CONSOLE Carbon (BR-BR) DI DI DI (BR-BR) O <tho< td=""><td>TO</td><td>(G=BK)</td><td>1012</td><td>-0</td><td>0-02</td></tho<>	TO	(G=BK)	1012	-0	0-02
CONSOLE Consol. Consol. <t< td=""><td>STATION BUSY</td><td>(BK=BP)</td><td>DI</td><td>-9-</td><td>0-0</td></t<>	STATION BUSY	(BK=BP)	DI	-9-	0-0
VITH DSS CARAST B GRD O	CONSOLE	(BR-BK)	000 0	-10*	0-0
GR-3 0 BKD 0 <td>WITH DSS</td> <td>(DK-DA)</td> <td>D GRU</td> <td>-0</td> <td>0-0</td>	WITH DSS	(DK-DA)	D GRU	-0	0-0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		(S-PK)	D GRU	-0	0-0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		(Y-BI)	D GRU	10	0-03
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		(PL-V)	B CPD	-0	0-0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		(V-0)	D GRD	10	0-0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		(0-2)	D GRU	-0	0-0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		(V-C)	TTC	-0	0-0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		((TTC	10	0-03
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		(V-00)	TTO	10	0-0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		(1-DR)	110	-0	0-0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		(V-C)	LIC	0	0-0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		(1=5)	LA	-0	0-0
$\begin{array}{c c c c c c c c c c c c c c c c c c c $		(1) (1)	001	-9.	0-04
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		(V-BL)	CGO		0-0
(V=0) 12 0 <td></td> <td>(BL-V)</td> <td>Y1</td> <td>10</td> <td>0 0</td>		(BL-V)	Y1	10	0 0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		(0-1)	12	-0	0-0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		(1-0)	13	0	0 0
(U-V) IS 0 0 0 (V-BR) B BAT 0 0 0 (BR-V) B BAT 0 0 0 (V-S) B BAT 0 0 0 (V-S) B BAT 0 0 0 (S-V) B BAT 0 0 05		(C-V)	T4	-0	0-04
(N=5K) B BA1 0 0 0 (BF-V) B BAT 0 0 0 0 (V-S) B BAT 0<	117	(V-PP)	CT CT	-0	0 0
(BK+V) B BAT 0		(V-BK)	B BAI	-0	0 0
(V-S) B BAT 0 0 0 (S-V) B BAT 0 0 055		(BR-V)	B BAT	-0	00
(S-V) B BAT O O OS		(V-S)	B BAT	-0	0 0
		(S-V)	B BAT	10	0 056

* FACTORY PROVIDED STRAPS MUST BE REMOVED WHEN DSS CONSOLE IS CONNECTED. IF CONSOLE IS REMOVED, THE STRAPS MUST BE REPLACED.

Fig. 41-Connections for One DSS Console

Note: The selector may be repeatedly recalled (without losing the seized intercom path) by repeatedly depressing the RECALL

	COLOR	LEAD DESIG	1	-	
	(W-BL)	SBI	D	EF	GH
	(BL-W)	SB2	To	-0	0-01
	(₩-0)	SB3	To	-0	000
	(0-W)	SB4	To	-0	0-0
	(W-G)	SB5	To	-0	0-0
	(G-W)	\$86	To	-0	0-05
	(W-BR)	S87	To	-0	00
	(BR-W)	SB8	To	-0	00
	(₩-S)	\$89	L	-	~
	(S-W)	SBIO	L	-	~~~~
	(R-BL)	SBII	To	~	~~~~
	(BL-R)	SB12	T	-	~
	(R-0)	SB13	To	-0	0-0
	(0-R)	SB14	To	-0	00
	(R-G)	SB15		-0	
	(G-R)	S816		0	0015
	(R-BR)	SB17	La	0	~
	(BR-R)	SB18	Lo	-0	
	(R-S)	SB19	To	-0	00
	(S-R)	18V±	To	-0	0-0
	(BK-BL)	18V±	To	-r	0-020
	(BL-BK)	18V±	To	ľ	20
	(BK-0)	18V±		T.	~
	(0-BK)	18V±	L	ľ	~
N BUSY	(BK-G)	18V±		ľ	~~~~~
E WITH	(G-BK)	MWI	L	~	~~~~
36	(BK-BR)	MW2		I*	~~~~
IG	(BR-BK)	MW3		0	000
	(BK-S)	MW4	T	0	
	(S-BK)	MW5	To	0	0-0
	(Y-BL)	MW6	T	0	0-000
	(BL-Y)	MW7		0	00
	(Y-0)	MW8	T	0	0-0
	(0-Y)	MW9		0	~
	(Y-G)	MWIO	T	0	0-0
	(G-Y)	MVL1	To	0	0-030
	(Y-BR)	MW12	T	0	00
	(BR-Y)	MW13	To	0	000
	(Y-S)	MW14	T	0	0-0
	(S-Y)	MW15	T	0	0-0
	(V-BL)	MWI6	To	ľ*	0-01
	(BL-V)	MW17	T	0	00
	(V-0)	MW18	To	0	0 0
	(0-V)	MW19	To	0	0-0
	(V-G)	10V±	To	0	0 0
	(G-V)	IOV±	To	0	0.010
	(V-BR)	10V±	To	0	0 0
	(BR-V)	IOV±	To	0	0 0
	(V-S)	IOV±	10	0	00
	(S-V)	107	10	0	0 0
			-		

TO STATIC

CONSO

MESSA

WAITI

* BE SURE FACTORY PROVIDED STRAPS ARE IN PLACE WHEN THE SYSTEM IS NOT EQUIPPED WITH A DSS CONSOLE.

Fig. 42-Connections for One MW Console

button and the DSS button. If intercom call is answered at any point, you must hang up and start over.

P/O CONN BLK 3

- 4.88 To page from the 6A1/DSS console:
 - (1) Lift handset on the associated telephone set.
 - (2) Select idle intercom path and depress intercom button.
 - (3) Momentarily depress PAGE button on DSS console-tone burst will be heard over paging system loudspeakers.
 - (4) Speak into handset transmitter to make announcement.
 - (5) Replace handset.

Station Busy Console (6B1) With MW

4.89 By depressing the appropriate button on the 6B1 console, an attendant may signal any station that there is a message waiting by lighting the lamp under the station HOLD button. The console also provides the attendant with a visual indication of a busy station. Seventeen buttons on the console correspond to the station codes (3 through 19); three buttons are not used. See Fig. 88 for schematic of 6B1 console.

4.90 To signal an intercom station that there is a message waiting at the attendant, the attendant depresses the MW button associated with the desired station. The button will lock down in a partially depressed state causing the lamp under the HOLD button of the called station to light (steady). This steady lamp alerts the station user that he has a message waiting and to call the attendant. When the station calls the attendant, the attendant then depresses the associated MW button to release it.

Note: When more than one MW console is installed, the MW signal can only be retired at the console originating the signal since the key must be physically released.

4.91 The station busy feature of the 6B1/MW console is similar to that of the 6A1/DSS console described in paragraph 4.85.

Caution: Although all CO/PBX and intercom line buttons may be unoperated, a busy station indication is displayed

at the 6A1/DSS or 6B1/MW console when a station handset is left off-hook.

N. Multiple Consoles

4.92 Although the 570-type KSU was originally designed for one station busy console, up to three consoles in any combination can be supplied. Extra power and, in some cases, additional terminations are required. Extra power is required because the ± 18 -volt supply in the KSU is capable of powering only one console. Each additional console requires one ampere at ±18 volts. The additional power can be supplied by a separately ordered and installed 215C1 power unit. Use a separate 18-gauge wire for each ±18-volt lead required. In addition, the ground terminals of the 215C1 power unit should be strapped to the ±18-volt ground terminal of the KSU power unit (Fig. 43). A 215C1 power unit fused for ±18 volts can be used for three leads.

4.93 The connections for multiple consoles are shown in Fig. 44 through 50. Refer to Table N for console connection figures. Since there are terminations for only one DSS and one MW console within the KSU, additional blocks which must be mounted external to the KSU are required when more than one console of either type is required. When 66M1-50 blocks are used, B bridging clips are used as straps for common leads. Where a second wire must be connected to a terminal, 183B2 adapters are used.

4.94 In any installation requiring a DSS console, the factory-provided D0-D1 strap (26E to 27E) and the CG0-CG1 strap (40E to 41E) on block 3 of the KSU must be removed. If all DSS consoles are removed, the straps must be replaced. When more than one DSS console is required, the CG0-CG1 leads must be wired in a series loop.

4.95 At multiple console installations, the station busy and message waiting features for the attendant station (station 0) can be activated if desired. The DSS feature is **not** activated, and intercom calls from the second and/or third multiple console station must be made by dialing.

- 4.96 To activate station busy and message waiting for station 0:
 - (1) Remove the power failure transfer feature at station 0, if provided (see Fig. 38). If



* DANGER: DO NOT CONNECT POWER CORD WHILE 19C2 IS TURNED ON.

Fig. 43-215C1 Power Unit Wiring

TABLE N

CONSOLE CONNECTION INDEX (SEE NOTE)

		NUMBER OF MW (6B1) CONSOLES						
	1	0	1	2	3			
SS les	0		Fig. 42	Fig. 46	Fig. 50			
of D onso	1	Fig. 41	Fig. 44	Fig. 48				
mber A1) C	2	Fig. 45	Fig. 47					
Nul (64	3	Fig. 49						

Note: Determine number of DSS consoles and MW consoles to be installed and select applicable connection diagram from table.

the feature must still be provided, a separate pair of wires must be run back to the KSU.

(2) Install the ring transfer option in the attendant station 0 telephone set if not already wired (Fig. 32). (3) At the station 0 telephone set, move the (V-S) mounting cord lead from terminal 21 to 8 and the (S-V) cord lead from terminal 20 to 28.

 (4) At the KSU, strap terminal 1A of block 1 to terminals 1D and 1E of block 3. Also strap 1B of block 1 to 26D of block 3. Use 183C2 adapters if required.

(5) Block the station 0 button inoperative (second button in bottom row) on any DSS consoles installed.

O. Station Restriction

4.97 This feature prevents any outgoing CO/PBX calls from being made at a restricted station.

4.98 The restricted station may receive calls, but cannot call out on CO/PBX lines. This is accomplished by adding a diode (rotary dial sets only) and reversing two leads in the telephone set. On TOUCH-TONE sets, two leads must be reversed in the telephone sets (see Table O.)

TO MA CONSOL

COLOR	DESIG	P/0 C0	IN RIK 3		DESIG	90.00	
/	00010	170 001	E C H	1 /		COLOR	~
(W-BL)	SB1	100	2 0001		SB1	(W-BL)	- 1
(BL-W)	SB2		0-0		SB2	(BL-W)	-
(W-0)	SB3		000		SB3	(W-0)	_
(0-W)	SB4		0-0		SB4	(0-W)	
(W-G)	SB5	100	0-05		SB5	(W-G)	
(G-W)	SB6	100			SB6	(G-W)	
(W-BR)	SB7	100			SB7	(W-BR)	
(BR-W)	SB8				SB8	(BR-W)	
(H-S)	SB9	100	000		SB9	(W-S)	_
(S-W)	SB10		0 010		SB10	(S-W)	_
(R-BL)	SB11		0010		SB11	(R-BL)	
(BL-R)	SB12		000		SB12	(BL-R)	
(R-0)	SB13	100	000		SB13	(R-0)	
(0-R)	SB14	100	000		SB14	(0-R)	
(R-G)	SB15	1000	0_0		SB15	(R-G)	
(G-R)	SB16	1000	0-015		SB16	(G-R)	
(R-BR)	SB17	1000	0-0		SB17	(R-BR)	-
(BR-R)	SB18	100	0-0		S818	(BR-R)	-
(R-S)	SB19	100	0-0		SB19	(R-S)	-
(S-R)	+18V	100	0-0	-	+18V	(S-R)	-
(BK-BL)	+18V	100	0-020		+18V	(BK-BL)	
(BL-BK)	+18V	100	0-0		+1 V	(BL-BK)	-
(BK-0)	+18V		0-0		+1: Y	(BK-C)	- n
(0-BK)	+18V	100	0-0		+18.7	(0-BK)	- 0
(BK-C)	+18V	100	0-0	TERMINATE	+18V	(BK-G)	- ~
(G-BK)	MM1	00	0-025	ON	DO	(G-BK)	
(BK_BS)	ML/2	10 9	0-0	COLUMN	01	(BK-BR)	-
(BR-BK)	MU3	0 02	0-0	E	B GRD	(BR-BK)	- 1
(BK-S)	MM4	0 0	100	1 1 1 1 1 1	B GRD	(BK-S)	-
(S-BIC)	MUS	0 0	60		B GRD	(S-BK)	- 1
(Y-BL)	MM6	0 0	0~030		B GRD	(Y-BL)	-
(BL-Y)	MW7	0 0	00	DEMONE	B GRD	(BL-Y)	-
(Y-C)	MUS	0 0	0-0	STRADS	B GRD	(Y-0)	-
(0-Y)	MUG	0 0	000	SIMAPS	TTC	(0-Y)	-
(v_c)	MUSO	00	0-0/		TTC	(v-r)	-
	MU11	0 0	0 0 35		TTC	(1-4)	-
(V-RP)	MU12	0 0	000		TTC	(U-1) (V.RD)	-1
(1-bR)	MW 1C	0 0	1000		110	(1-br) (pp v)	-
(DR-1)	PIW17	0 0	1000		LIC	(1-nd)	-
(C.V)	PW 14	0 0	1 0-0		CCT	(1-5) (c v)	-
(1-1)	MN 12	0 94	0-040		661	(3-1)	- 1
(V-0L)	MW 10	0 0	0-0		VI	(V-DL) (DL V)	-
(BL -V)	MW17	0 0	0-0		¥1	(BL-V)	-
(0-0)	MWIB	0 0	0-0		YC	(V=0)	-
(0-V)	MW19	0 0	0-0		¥3	(0-V)	-
(V-G)	+100	0 0	0-045		Y4	(V-G)	-
(0-V)	+100	0 0	0-0		17	(6-7)	-
(V-BR)	±10V	0 0	0-0		B BAT.	(V-BR)	-
(BR-V)	+10V	0 0	0-0		B BAT.	(BR-V)	-
(V-S)	+10V		0-0		B BAT.	(V-S)	-
(S-V)	+10V		0 000		B BAT.	(S-V)	-
		1 0 0					1

REMOVE ±18V FUSE ON 19C2A POWER UNIT IN KSU * INSTALL 18382 BRIDGING ADAPTER ON COLUMN E, ROWS 22-23 TO ENABLE CONNECTION OF EXTERNAL ±18V POWER SOURCE.

Fig. 44—Connections for One MW Console and One DSS Console

Page 64

518-450-100-i04 1979-04-064.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 21:54:16



66MI -50 CONN BLOCK

- I. CUT DOWN CABLE FROM FIRST DSS CONSOLE ON COLUMN B EXCEPT FOR CGO (V-BL) LEAD.
- 2. CUT DOWN CABLE FROM SECOND DSS CONSOLE ON COLUMN C EXCEPT FOR CGI (S-Y) AND CGO (V-BL) LEADS.
- 3. BE SURE THAT FACTORY-PROVIDED STRAPS BETWEEN E26 AND E27 AND E40 AND E41 ON KSU ARE REMOVED.
- * INSTALL STRAP.

Fig. 45—Connections for Two DSS Consoles

SECTION 518-450-100







Caution: Make sure bare leads of the diode do not come into contact with the case of the network, other network terminals, or other parts of the telephone set. Use insulating sleeving where required.

P. TOUCH-TONE Dialing

4.99 Where TOUCH-TONE dial telephone sets are used with the 7A Communication System;
a 440A (MD) or 478B KTU (TOUCH-TONE adapter) is required. These are the only TOUCH-TONE



I. CUT DOWN CABLE FROM FIRST DSS CONSOLE ON COLUMN B

EXCEPT FOR CGO (V-BL) LEAD. 2. CUT DOWN CABLE FROM SECOND DSS CONSOLE ON COLUMN C

EXCEPT FOR CGI (S-Y) AND CGO (V-BL) LEADS.



adapters usable in this system and are installed in J13 and J14. See Fig. 51 for KTU location.

> Note: Do not use a 494A KTU (TOUCH-TONE selector) with COM KEY 718 due to an incompatibility with the DSS console circuitry.

The adapter converts the multifrequency tones from the telephone set dial to contact closures which

supply ground to the proper leads in the code selector circuit, 424B or 424C KTU.

4.100 When the adapter used is a 478B, be sure that A and B ground are available at the J13/14 connector (Fig. 74 and 85). If these grounds are not connected, install the D-180720 Kit of Parts supplied with the 478B KTU. Figure 52 is a

Page 6

518-450-100-i04_1979-04-068.jpg

Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 21:56:18



P/O CONN BLK 3 ON KSU

66MI-25 CONN BLOCK

Fig. 48—Connections for One DSS Console and Two MW Consoles

TO DSS CONSOLE



4. BE SURE THAT FACTORY-PROVIDED STRAPS BETWEEN E26 AND E27 AND E40 AND E41 ON CONN BLOCK 3 ON KSU ARE REMOVED.





Fig. 50-Connections for Three MW Consoles

duplication of the instruction sheet supplied with the kit of parts.

4.101 Remove the RS1 to CG strap in column A of connecting block 1 when any TOUCH-TONE adapter KTU is installed (Fig. 53). Q. Automatic, DC Signaling, Private Line Circuit

4.102 Private line service can be supplied in the 570B KSU only if music-on-hold

is not also being furnished. A circuit incompatibility exists between the private line circuit and the music-on-hold circuit. A 415A KTU is

TABLE O

STATION RESTRICTION CONNECTIONS

	ТҮРЕ		INSTALL	MOVE LEAD	
	TEL SI	DIODE		FROM	то
		1.08	RR F	poruls I a	in jack
	832	(G)		22	4
	21.0.0	(R)		4	22
	0000	(G)		22	4
	2032	(R)		4	22

- Unit fastaned scorride and monited in a

Londspersers

industa second cars the scinite a

and a more threated and a manager information



a device therease allowing the state of the

they want day

Fig. 51—Location of 440A (MD) or 478B KTU TOUCH-TONE Adapter

a de bourier mountes la propos antinentes sui faid na anonanos la parternad en al

SECTION 518-450-100

required for each private line circuit desired and is plugged into the KSU in place of one of the CO/PBX line circuits. Each private line installed will reduce the number of CO/PBX lines by one. In addition, a 415A KTU or equivalent is required at the distant end.

4.103 Install the 415A KTU in jacks 1 through 7 and connect tip and ring to the distant end to block 3 with the incoming CO/PBX lines (Fig. 25).

5. GENERAL MAINTENANCE

5.01 Maintenance of the 7A Communication System is limited to normal station repairs and wiring checks of the KSU and replacement of defective components.

- 5.02 For more detailed maintenance information, refer to Part 6 of this practice.
- 5.03 When trouble is encountered, first make a thorough check of all connections, then make the following checks before replacement of KTUs, power unit, or KSU is considered.
 - (a) 570-Type KSU
 - Fuses in place and not blown
 - Lamps not burnt out
 - KTUs securely mounted in proper connectors with retainers and/or guide asemblies in place
 - Wiring checked on connecting blocks.

(b) Externally Mounted Units

33A Voice Coupler

- Fuses positioned properly and not blown
- COAM music source operative and meets requirements in paragraph 4.37.

20A-49 Apparatus Unit

- Volume control (potentiometer) not turned off on unit
- Volume control (potentiometer) not turned off on loudspeakers.

22A-49 Apparatus Unit

• Unit fastened securely and mounted in a vertical position.

Loudspeakers

· Wiring and connections checked.

No field maintenance is to be performed on the externally mounted units.

- (c) **KTUs**
 - Securely placed in proper connectors.
 - Replace a suspected KTU with one known to be in good working order to determine whether trouble is in KTU or external to it.
 - Should the replacement KTU not clear the trouble, the trouble is external and the original KTU should be returned to service.

No field maintenance is to be performed on KTUs.

- (d) Power Unit
 - Fuses in place and not blown
INSTALLATION INSTRUCTIONS FOR D-180720 KIT QF PARTS (570A KSU)

This instruction sheet is intended to assist the installer when equipping a 478B KTU in 570A KSUs having serial number 16390 or lower. These KSUs require AGRD and BGRD wiring on connectors J13 and J14 when a 478B KTU is to be equipped in place of a 440A KTU. Discard this kit of parts if 478B KTU is to be equipped in 570A KSUs having serial number 16391 and higher.

PROCEDURE

- 1. Remove cover from KSU.
- 2. Open right gate.
- 3. Connect wires as shown below by following cable paths and tying in place where needed. Connections are made by sliding terminals of each lead assembly on to connector wire-wrap contacts.

Signal	From	To
AGRD	J9-3 or J10-3	J13-3,J14-3
BGRD	J10-37	J13-15, J14-15



- 4. Plug 478B KTU in connectors J13 & J14.
- 5. Close and lock gates.
- 6. Reassemble cover on to KSU.

Fig. 52—Instruction Sheet for D-180720 Kit of Parts





Fig. 53—Removal of RS1 to CG Strap for TOUCH-TONE Intercom

- AC power cord properly secured in both the ac receptacle and the power unit connector
- Power present at the ac receptacle
- · Circuit and frame grounds properly connected.

(e) Telephone Sets

- Set plugged in securely
- · Volume control not turned off
- Lamps not burnt out.

A. Trouble Analysis

5.05 Table P is to be used as an aid to diagnose and correct troubles in the system. The troubles should be identified before using the table; then the cause may be recognized and a solution effected.

6. DETAILED MAINTENANCE

6.01 Maintenance information is included as an aid in locating and clearing trouble in the 7A Communication System at the time of installation or on subsequent repair visits. Analysis of the trouble reported may be helpful in narrowing the search for the source of trouble. For instance, if a lamp does not light at a particular station or group of stations, the trouble is more likely in a

telephone set or its wiring—if the lamp does not light at any station, the trouble is more likely in the KSU.

- 6.02 Maintenance information for the following circuits is provided:
 - CO/PBX line circuits-400-Type KTU
 - CO/PBX line ringing arrangements
 - Power failure transfer circuit-452A KTU
 - Intercom circuits—424-type, 440A (MD) or 478B, 456-type, 460B KTUs
 - Paging circuit-457C KTU
 - · Background music
 - Music-On-Hold-451-Type or 498A KTU
 - Power distribution.

6.03 If analysis and/or testing indicates trouble in the KSU, the source can be further identified using the supplied information in the following sequence:

 The description of each circuit and the purpose of the KTUs can be used to determine what units may be involved.

(2) Once the involved circuit has been determined, use the sequence table which gives an operational procedure for testing the circuit and, where a failure is encountered, the most likely causes or KTUs that could cause the condition.

(3) If the trouble is suspected in or isolated to a particular KTU, further aids are given in the form of a lead table and an input and output table. The lead table defines each lead, its function in the circuit, and its termination on the KTU and mating connector(s). The input and output table can be used to ensure that proper potentials are available at, or being supplied by, the KTU under any circuit conditions shown required in the Remarks column. Only tests that can be made with a 1013A hand test set or equivalent have been included. Further tests are possible but may require more sophisticated test equipment. If the KTU tests defective, replace it.

TABLE P

TROUBLE ANALYSIS TABLE

TROUBLE	POSSIBLE CAUSE	POSSIBLE SOLUTION
	a. Incoming CO/PBX line is dead.	Check incoming tip and ring with test set.
	b. Incoming tip and ring terminated on the wrong terminals.	Check connections.
Factor 1	c. Line circuit (400-type KTU) not plugged in correctly.	Check that KTU is properly seated in connector and is located in the right connector. See Fig. 6.
No side tone on	d. Diode(s) in polarity guard may be defective.	Replace diodes with ones known to be good.
CO/I DA line.	e. Switchhook pileup on telephone set is defective.	Change out telephone set.
1	 Privacy circuit in the telephone set may be operating (if the set is equipped with a privacy circuit). 	Check to see if privacy relay is falsely operating when going off-hook.
101.14	g. If dial restriction diode is installed in the set, tip and ring may be reversed.	Check station cutdown and polarity of dial restriction diode.
Line busied out	a. Lamp and A leads reversed.	Check station cutdown for that line.
(lamp steady).	b. Lamp and A leads shorted.	Check station cutdown for that line.
Dial tone over an answered call or two lines seized together.	a. Two lines conferenced from an idle station set.	Check stations to ensure that no idle sets have more than one line button depressed.
Intercom oscillates (repeatedly	a. Selector (424B/424C KTU) not plugged in correctly.	Check that KTU is properly seated in connector and is located in the right connector. See Fig. 6 and 24.
comes up; then drops) when	b. D0-D1 strap is missing (if no DSS console is provided).	Check option strap. See Fig. 41.
seized.	c. DSS console unplugged or not con- nected (if DSS console is provided).	Check DSS console cutdown. Check that DSS console is properly plugged in.
Incorrect intercom codes are dialed (TOUCH- TONE dial set).	a. Y3 relay in selector (424B/424C KTU) is not dropping.	Check that RS1-CG strap is removed. See 4.99 and Fig. 53.

TABLE P (Contd)

TROUBLE ANALYSIS TABLE

TROUBLE	POSSIBLE CAUSE	POSSIBLE SOLUTION	
Incorrect intercom codes are dialed when using DSS con- sole.	a. Y3 relay in selector (424B/424C KTU) is not dropping.	Check that CG0-CG1 strap is removed. See Fig. 41.	
Cannot dial on intercom. On going off-hook. calling station hears tone burst.	 a. 478B or 440A KTU is not plugged in correctly. b. Rotary dial system with CG-RS1 strap missing. c. If DSS console is provided, connections may be bad. d. Grounded network. 	Check that KTU is properly seated in connector and is located in the right connector. See Fig. 6 and 51. Check CG-RS1 strap. See Fig. 3 or 53. Check DSS console cutdown. Check that console is properly plugged in. Clear ground or replace network.	
Hold lamp on attendant's set is always lit.	a. Attendant set is not modified or is improperly modified.	Disable hold lamp at attendant's set (3.17).	
No music- on-hold or distorted music-on- hold.	 a. 451A/451B KTU is not plugged in properly. b. Music source volume too low. c. Music source unable to drive the 451A KTU. d. Blown fuse or improperly wired 33A voice coupler. 	Check that KTU is properly seated in con- nector and is located in the right con- nector. See Fig. 6 and 30. Gradually increase volume while listening. See 4.37. Source must be approx. 8 ohms or less. Check fuses in 33A and verify wiring.	
Low or no volume on ringing or voice signaling.	a. Volume control turned off or set too low.b. Defective volume control.c. Defective speaker.	Turn on or adjust volume control. Replace telephone set. Replace speaker.	
False hold condition when changing lines or lightly touching line buttons.	a. Incorrect sequence of BD contact on line key.	Replace key or replace telephone set.	
Low output from paging speaker.	a. 20A-49 potentiometer set too low.b. Wrong speakers used.	Adjust potentiometer on 20A-49 apparatus unit. Use only 45-ohm speakers.	

TABLE P (Contd)

TROUBLE	ANALYSIS	TABLE

TROUBLE	POSSIBLE CAUSE	POSSIBLE SOLUTION	
-	a. 457C KTU is not plugged in correctly.	Check that KTU is properly seated and is in right connector. See Fig. 35.	
Cannot	b. Speakers wired wrong.	Check connections. See Fig. 36.	
	c. Defective speaker.	Replace speaker.	
transmit over	d. Wrong speaker used.	Use only 45-ohm speakers.	
speakers.	e. Speaker located too far from KSU.	Use quad wire. Speaker should be within 320 feet of KSU.	
	f. Potentiometer in K8 speaker turned too low.	Adjust potentiometer.	
	a. 457C KTU is not plugged in correctly.	Check that KTU is properly seated and is in right connector. See Fig. 6 and 35.	
	b. Potentiometer in 20A-49 apparatus unit turned too low.	Adjust potentiometer.	
	c. Customer's paging system turned	Proceed as follows:	
Cannot transmit over COAM paging system.	or Trouble in COAM paging equipment.	 Test for hazardous voltages at terminals A1 and A2 of 20A-49 apparatus unit. Remove customer's connections from terminals A1 and A2. Have attendant dial paging code. Monitor across terminals A1 and A2 with 1012A test art 	
		 5. If attendant can be heard with 1013A test set, advise customer of results of test. <i>Do not</i> attempt any tests or repairs on customer's equipment. 	

Note: No attempt should be made to repair or modify KTUs in the field. Replace defective KTUs with one known to be in working order. If replacing a KTU does not clear the trouble, *the original unit should be put back in service.*

(4) If trouble is indicated in the factory wiring of the KSU, a point-to-point wiring schematic is furnished for each circuit. The distribution of all power in the KSU is also separately supplied in case it is found a particular potential is missing. Any wiring that is not designated by color will consist of standard strapping. All factory wiring is shown as solid lines—dashed lines indicate wiring external to the KSU or installer placed.

Line Circuits-400-Type KTU

6.04 The 400-type KTU provides the control functions between one CO/PBX line and the telephone sets, including line pickup, hold, lamp and tone ringing control. The KTU also assures outgoing service during power failure. Option straps should be placed on the 400A through G

SECTION 518-450-100

KTU when used with the 7A Communication System to provide short timeout (Z), lamp wink on hold (Y), and interrupted audible signal (W). The 400H KTU should have the CO/PBX line option (T) and interrupted ring (W). The hold abandon option (S or R) will depend on the serving central office.

6.05 Tables Q, R, S, and Fig. 54 through 67 are provided as an aid for maintenance of the CO line circuits.

CO/PBX Line Ringing Arrangements

6.06 Provision is made to program several arrangements involving ringing on the CO/PBX lines. These include:

- Common audible—as factory-wired, station 0 will receive all incoming CO/PBX calls (option K)
- The common audible can be moved to a different station by replacing option K with a jumper from terminal 9F to the desired CO() lead
- The CO/PBX lines can ring at additional stations other than the attendant by connecting the RC leads to the CO leads (option S)
- Calls can be transferred to one alternate station other than the attendant by adding option J on block 1.

Note: In any of the arrangements, a maximum of 10 stations can be wired to ring on common audible. However, a station cannot ring on more than one line.

6.07 Tables T, U, and Fig. 68 are provided as an aid for maintenance of the CO/PBX ringing arrangements.

Power Failure Transfer Circuit-452A KTU

6.08 This circuit provides for incoming audible signals on an optional basis in the event of loss of commercial power or operation of the -24V relay battery fuse (B battery) in the 570-type KSU. The tip and ring of each CO/PBX line is brought through normally closed contacts on the 452A KTU relays. These relays are operated as long as B battery is supplied to the KSU. If the battery is lost, the relays release, extending the lines to

Page 78

connecting block 1 where a cross-connect must be placed (Fig. 38). The cross-connect in turn extends the tip and ring to the (V-S) (S-V) pair of the desired extension. An external ringer must be connected to these leads at the telephone set or some other accessible point.

6.09 Tables V, W, X, and Fig. 69 are provided as an aid for maintenance of the power failure transfer circuit.

Intercom and Paging Circuits—424B or C, 440A (MD) or 478B, 456A or B, 457C, and 460B KTUs

6.10 The intercom circuitry provides two separate paths for calls within the system with each

paths for calls within the system with each path appearing on a button on the telephone sets. Basic intercom features are supplied by the following KTUs:

- 424B or C KTU-Selector circuit
- 456A or B KTU-Voice and tone alerting circuit
- 460B KTU-2-path access circuit.

To provide the optional intercom features, the following additional units are required:

- 440A (MD) or 478B KTU-TOUCH-TONE adapter circuit
- 457C KTU-Paging amplifier circuit.

An additional optional feature, intercom preset conferencing, can be supplied by making wiring changes on the connecting block field.

A. Selector Circuit-424B or C KTU

6.11 This circuit is the basic, selector-only, 19-code rotary intercom circuit. Of the available codes, 0 is used as the attendant code, 1 is the first digit of the 2-digit codes, 2 is the paging code, and 3 through 19 are assigned as station codes. The 424B or C KTU selects and alerts the desired intercom station. Station selection can be by rotary dial, TOUCH-TONE dial, or DSS console, if provided.

TABLE Q

400-TYPE KTU LINE CIRCUIT



TABLE Q (Contd)

400-TYPE KTU LINE CIRCUIT

With party on line, depress HOLD.



Go on-hook, lamp extinguished. Circuit normal.

B. TOUCH-TONE Adapter Circuit—440A (MD) or 478B KTU

6.12 The adapter circuit is used to convert the multifrequency signals from the station to contact closures which supply ground on the proper Y1-Y5 leads to the 424B or C selector. Operation of the proper counting relays in the selector alerts the designated station in the same manner as for a rotary dial call. The adapter also grounds the LK lead after the first digit of a 2-digit code is dialed to remove dial tone. When the adapter is not in use, a path is completed through the H and L relays for the CG0-CG1 lead which operates the selector counting relays on rotary dialed calls.

C. Voice and Tone Alerting Circuit—456A or B KTU

6.13 The 456A or B KTU consists primarily of an oscillator circuit and a preamplifier circuit. The oscillator is designed to give a 1-second burst of tone as the alerting tone on intercom calls. The preamplifier is used for the voice signaling. A voice input to the paging circuit (optional) is also furnished from this circuit.

D. 2-Path Access Circuit—460B KTU

- 6.14 The 460B KTU performs the following functions:
 - Provides talk battery for the two intercom paths
 - Controls all intercom lamp functions
 - Provides the common control circuitry to connect the selector to one path at a time and a detect circuit to free the selector at the proper time if a second intercom call is waiting, and connects the tone alert and TOUCH-TONE adapter (if provided) to the selected path
 - Connects dial tone to the tip of the intercom path selected.

	-		-	
- T A	ы			
10			•	
	_	_		

LEAD TABLE-400-TYPE KTU

LEAD DESIG.	EAD FUNCTION ESIG.	
A lead—primary control lead from telephone set. A Status of A lead determines idle, off-hook, or hold indication.		16
L	Lamp lead—provides proper 10V ac signal to tele- phone set lamp to indicate line status.	8
R(CO)	Ring side of CO/PBX line from office.	9
R(STA)	Ring side of line-output toward station.	13
T(CO)	Tip side of CO/PBX line from office.	14
T(STA)	Tip side of line-output of KTU toward station.	12
RC	Ringing control—tone signal control lead. Connects tone from generator to amplifier of telephone set as an audible signal.	1

6.15 Tables Y, Z, AA, AB, AC, AD, and Fig. 70 are provided as an aid for maintenance of the intercommunications circuits.

E. Paging Circuit—457C KTU

6.16 The paging circuit is enabled by dialing a digit 2 on either of the intercom paths. This completes a circuit between the SS lead from the 456B KTU through the selector to the PC lead in the 457C KTU. This applies the input on the PA lead from the 456B KTU to the amplifier, and short-circuits the input from the CP music source on leads MT and MR, if provided. Voice and tone inputs on the PA lead are then heard in the speakers.

6.17 Tables AE, AF, AG, and Fig. 71 are provided as an aid for maintenance of the paging circuit.

Background Music

6.18 Background music can be supplied over the paging speaker when paging is not taking place, using the amplifier circuitry in the 457C

KTU. The CP music source is fed through a 33A voice coupler which acts as a combination interface and protective device. The level of the sound at the speakers involves interaction of the volume control settings at the music source, voice coupler, and the individual speakers.

Music-on-Hold-451-Type or 498A KTU

6.19 The same music source used for background music can be multipled at the 33A voice coupler to furnish music-on-hold. The 451-type KTU or a 498A equipped with a 116A1 CM is required to furnish an output to the seven CO/PBX lines. When the lines are in a talk condition, the output of the 451-type KTU is shorted by contacts in the associated line circuit. When placed on hold, the output is impressed on the ring side of the CO/PBX line and can be heard by the held party. The 498A KTU recognizes changes on the A and L leads in the hold condition. When the line is placed on hold, the 498A KTU provides a balanced music connection on the tip and ring.

6.20 Tables AH, AI, AJ, AK, and Fig. 72 are provided as an aid in the maintenance of

TABLE S

INPUTS AND OUTPUTS-400-TYPE KTU

TEST FROM	то	MON/TALK SWITCH	TEST FOR	REMARKS
			INPUTS	ing- bend - pr
14	9		CO/PBX dial tone	POLITICAL DE LA COMPANY
BBAT	15	TALK	B Ground	
0.011	6		MG — interrupter ground	
	2		LW - 10V± at 120 IPM	With intermentar maning
GROUND	7	MON	LF - 10V± at 60 IPM	with interrupter running
or 15	4	MON	10V steady	Ne man est i filia
	11		RN — interrupted tone ringer signal	
	17	TALK	B Battery	Interrupter running
			OUTPUTS	abations mil
12	13	TALK	CO/PBX dial tone	
CROUND	8	MON	10V± steady	Ground pin 16
GROUND	1 M	MON	Tone ringing signal	CO/PBX ringing on line

background music and music-on-hold circuits using a 451-type KTU in a 570A KSU (MD).

6.21 Tables AH, AI, AL, AM, and Fig. 73 are provided as an aid in the maintenance of music-on-hold circuits using a 498A KTU in a 570B KSU.

Power Distribution

6.22 Refer to Fig. 74 for power distribution circuit information.

the second that are the first one of the

and any believe as for some several to be a se



Fig. 54-First Line Circuit (570A KSU)





Fig. 55-Second Line Circuit (570A KSU)

SECTION 518-450-100



Fig. 56—Third Line Circuit (570A KSU)

ISS 4, SECTION 518-450-100

Page 85

518-450-100-i04_1979-04-085.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:02:14



KSU CONNECTOR

JI

≺ 38

•≺34

J18

×14

J5

+ 14

• 9

-12

<13

~8

-< 16

- REPRESENTS WIRING ON KSUS MANUFACTURED BEFORE MAY 1975.

F4

NOTE:

A 14



Fig. 57-Fourth Line Circuit (570A KSU)

CONNECTING BLOCKS

3

43A

444

13H -0-

13G

14H -0-

14G

15H

15G

16H

-0-

16G

2

16E

13E

13F

LIGF

0

VIEH

13H

16G





Fig. 58-Fifth Line Circuit (570A KSU)



Fig. 59-Sixth Line Circuit (570A KSU)

CONNECTING BLOCKS

3

474

48A

21H

216

22H

22G

23H -0-

236

24H

246

2

205

\$ 17E

17F

ZOF

176

£ 20G

SOH

SECTION 518-450-100

J18

-< 34

KSU CONNECTOR

JI

-12

· 13

J7

×14

×9

-12

13

8

<16

---- REPRESENTS WIRING ON KSUS MANUFACTURED

F6

NOTE:

BEFORE 1975.

518-450-100-104_1979-04-089.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:03:18



Fig. 60-Seventh Line Circuit (570A KSU)

ISS 4, SECTION 518-450-100



Fig. 61-First Line Circuit (570B KSU)





SECTION 518-450-100

Fig. 63-Third Line Circuit (570B KSU)

Page 92

518-450-100-i04_1979-04-092.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:04:10





Fig. 64-Fourth Line Circuit (570B KSU)

ISS 4, SECTION 518-450-100

Page 94



Fig. 65-Fifth Line Circuit (570B KSU)

SECTION 518-450-100

518-450-100-i04_1979-04-094.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:04:42



Fig. 66-Sixth Line Circuit (570B KSU)

KSU CONNECTOR

JI

< 12

×13

J18

< 13

< 31

< 27

J7

K14

×9

×12

×13

×8

K16

Page 96



Fig. 67—Seventh Line Circuit (570B KSU)

518-450-100-104_1979-04-096.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:05:28

TABLE T

CO/PBX LINE RINGING ARRANGEMENTS



TABLE U

LEAD TABLE-CO/PBX LINE RINGING ARRANGEMENTS

LEAD DESIG	FUNCTION
CO()	Central Office ringing lead—tone ringing is applied to this lead from RO lead of 455A KTU, interrupter, RN lead, 400-type KTU, RC() lead, common audible diodes, and cross-connect on block 1.
RT	Ring transfer—this lead transfers common audible ringing from CO(0) lead to designated alternate station under control of RING TR button at attendant set and jumper at block 1 (option J).
RC()	Ringing control—tone ringing output from 400-type KTU to common audible diodes on block 1.

surrow Optime 8 strago minister on blesh 1-row 24 for column Open CO () lines Defective test of mody Los and on loudspeakers

> at a tother and the fact of (0). (Elemine in a transfer only forther appointed on Other 17 and to whether allowed in the factor

PAULIAN

- mine as a language of the second of the seco
 - Souther the second seco
 - intercords, or defective at
 - Open OD () fault et allevents station
 - BING TR Foy at a reddent
 - Bautile ting transfer (emilied, defyeld); el improprify competent (00110, key;

The particular state of the sta

subliding horses to person and



518-450-100-i04_1979-04-099.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:06:17

ISS 4, SECTION 518-450-100

.





LEAD TABLE-452A KTU

LEAD DESIG.	FUNCTION	KTU/CONNECTOR PIN NO. J1
ET()	Tip of extension ringer circuit from station (V-S)	10
ER()	Ring of extension ringer circuit from station (S-V)	
EXT()	Tip side of audible circuit from KTU	1, 16, 28, 37, 27, 35, 8
EXR()	Ring side of audible circuit from KTU	31, 26, 29, 33, 22, 36, 14
T(CO)	Tip side of CO/PBX line from office	0, 20, 24, 38, 32, 12, 39
R(CO)	Ring side of CO/PBX line from office	19, 21, 25, 34, 23, 13, 30

TABLE X

INPUTS AND	OUTPUTS-452A K	TU
------------	----------------	----

TEST FROM	то	MON/TALK SWITCH	TEST FOR	REMARKS
		E.	INPUTS	a sela
GROUND	17	TALK	B Battery	-
17	9	TADA	B Ground	
			OUTPUTS	
1	31		CO/PBX ringing — Line 1	and the second
16	26		CO/PBX ringing - Line 2	
28	29		CO/PBX ringing - Line 3	Power plug disconnected
37	33	MON	CO/PBX ringing - Line 4	or -24V relay
27	22	-	CO/PBX ringing — Line 5	fuse removed
35	36	1	CO/PBX ringing — Line 6	
8	14	(-1-3)	CO/PBX ringing - Line 7	





Fig. 69—Power Failure Transfer Circuit

SECTION 518-450-100

518-450-100-i04_1979-04-102.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:07:08

TABLE Y

INTERCOM (IC) CALL

Lift handset and depress button associated with idle IC path (lamp dark). OK FAILURE Button flashes at 60 IPM. (a) No lamp IC dial tone heard. IT and/or IR of selected 1. Note: If other IC button path open-460B KTU. is flashing, dial tone will 2. Open A battery fuse-power not be heard until selector unit. is released. 3. Open lamp fuse-F13 or F14. 4. Interrupter not running-(MS and MG leads-460B. (b) No dial tone Defective dial tone 1. generator-460B. Selector not seized (D0-D1 2. leads); 424B/424C, 460B, DSS console. Open BR lead-424B/424C, 3. 460B. 4. IT and/or IR open-460B. Digit dialed. If 2-digit code, see 2-digit IC call. Single-digit code. FAILURE OK Dial tone removed. Tone burst Dial tone not removed (a) heard at calling station in Open LK lead-460B, 440A 1. handset and at called station or 478B, DSS console, in loudspeaker. 424B/424C. (b) Digit not dialed Defective selector-424B/424C. 1. 2. TC and/or RC lead open-460B, 440A or 478B. 3. Defective DSS console.

TABLE Y (Contd)

INTERCOM (IC) CALL



Page 104

518-450-100-i04_1979-04-104.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:07:45



TABLE Z

LEAD TABLE-INTERCOM CIRCUIT

LEAD DESIG	FUNCTION	KTU/CONNECTOR PIN NUMBER
BR	Switched B battery — when $424B/424C$ KTU is seized, this lead applies $-24V$ B to 460B KTU to start intercom dial tone.	J10-35 J12-35
BY1	Busy ground — applies ground after completion of dialing to enable the 2nd station detect circuit in the 460B KTU and start intercom ringing in the 456B KTU.	J10-19 J12-19 J16-19
CG1	Counter ground — applies ground to counting relays in 424B/424C either by M option strap or via DSS console Q option on non-TOUCH TONE calls.	J14-26
CG0	Counter ground — provides ground to counting relays (Y1-Y5) from RS2 lead (M option) or via 440A or 478B (N option) or via CG0 and CG1 leads of DSS console (Q option).	J10-21
D1	Off-hook detection — selector seizure output from 460B KTU (M option) or to D0 output of 460B via DSS console (Q option). If call is rotary dialed, D1 is also the dial pulse input from the 460B.	J10-16
D0	Dialing output — ground supply for talk battery when a path is seized; also, the seizure input for the 424B/424C selector by way of lead D1 if DSS is not provided (M option) or if provided (Q option) by way of the DSS console.	J12-16
· IL1	Intercom lamp $1 - $ lamp circuit for path 1 to station 0 and 3-19.	J12-8
IL2	Intercom lamp $2 - $ lamp circuit for path 2 to station 0 and 3-19.	J11-16
IR1	Intercom ring $1 - ring$ side of path 1.	J12-14
IT1	Intercom tip $1 - $ tip side of path 1.	J12-34
IR2	Intercom ring $2 - ring$ side of path 2.	J12-0
IT2	Intercom tip $2 - $ tip side of path 2.	J12-1
LF2	Intercom flash -60 IPM signal from the interrupter applied to all tel sets during the period an intercom path is seized until call is answered and selector is released.	J12-7

	TABLE Z (Contd)	
	LEAD TABLE-INTERCOM CIRCUIT	
LEAD DESIG	FUNCTION	KTU/CONNECTOR PIN NUMBER
LK	Dial tone disconnect — ground is applied to this lead by the selector after first digit of an intercom code is dialed to stop dial tone.	J10-30 J12-30 J14-26
LT2	Transfer digit 2 – provides ground from DSS console to operate TR, TR1 relays (codes 10-19).	J9-39
MG	Motor ground – ground to start interrupter motor when any intercom path is seized.	J11-6
MS	Motor start $-$ from interrupter motor circuit, starts interrupter from MG when any path is seized.	J11-5
PA	Paging signal — output to the paging amplifier (457C KTU). Paging (optional) speakers must be connected as shown in Fig. 36.	J16-0
RC	Calling ring – common ring of intercom circuits to voice and tone-alerting circuit and to TOUCH-TONE adapter.	J12-13 J14-13 J16-9
RH	R relay hold — ground from LK lead is applied on this lead to 424B/424C KTU to prevent ringing until all dialing is completed.	J10-26 J12-26
RS1	Reset — provides ground for 424B/424C KTU selector timer over RS2 lead. If TOUCH-TONE is provided, N option furnishes ground to the counting relays via the adapter.	J10-38 J14-38
RS2	Reset $-$ connected to RS1 (see above).	J9-19
SS	Station signaling input — when dialing is complete, this lead carries the tone burst to the selector where it is applied to the VS lead of the station selected.	J10-14 J16-1
TC	Calling tip – common tip of intercom paths to voice and tone-alerting circuit and TOUCH-TONE adapter.	J12-12 J14-12 J16-8
TD	Transfer digit — resets 424B/424C selector after 1st digit of a 2-digit code is dialed.	J9-16 J9-28

Page 107

ISS 4, SECTION 518-450-100

TABLE Z (Contd)				
	LEAD TABLE-INTERCOM CIRCUIT			
LEAD DESIG	FUNCTION	KTU/CONNECTOR PIN NUMBER		
TG	To ground — provides ground to selector timer via the RS1 lead.	J9-38		
TTG	TOUCH-TONE ground — supplies ground to control adapter when selector is seized (N option) or provides ground to DSS console selector relays (Q option).	J10-39 J14-36		
VS0	Station ringing — voice signaling lead — code 0.	J9-34		
VS3	Station ringing — voice signaling lead — code 3.	J9-25		
VS4	Station ringing $-$ voice signaling lead $-$ code 4.	J9-26		
VS5	Station ringing — voice signaling lead — code 5.	J9-20		
VS6	Station ringing — voice signaling lead — code 6.	J9-21		
VS7	Station ringing — voice signaling lead — code 7.	J9-32		
VS8	Station ringing — voice signaling lead — code 8.	J9-30		
VS9	Station ringing — voice signaling lead — code 9.	J9-29		
VS10	Station ringing $-$ voice signaling lead $-$ code 10.	J9-14		
VS11	Station ringing — voice signaling lead — code 11.	J9-8		
VS12	Station ringing $-$ voice signaling lead $-$ code 12.	J9-22		
VS13	Station ringing $-$ voice signaling lead $-$ code 13.	J9-24		
VS14	Station ringing – voice signaling lead – code 14.	J9-27		
VS15	Station ringing — voice signaling lead — code 15.	J9-0		
VS16	Station ringing $-$ voice signaling lead $-$ code 16.	J9-1		
VS17	Station ringing $-$ voice signaling lead $-$ code 17.	J9-33		

SECTION 518-450-100

Page 108

518-450-100-i04 1979-04-108.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:08:59
TABLE Z (Contd)

LEAD TABLE-INTERCOM CIRCUIT

LEAD DESIG	FUNCTION									KTU/CONNECTO PIN NUMBER		
VS18	Station ringing — voice signaling lead — code 18.									-	J9-31	
VS-19	Station ringing — voice signaling lea	ad —	code :	19.								J9-9
¥1	Selector counter relay No. 1 ground TOUCH-TONE adapter of DSS con	d — p sole.	orovid	es ground	to oper	ate Y1 co	unti	ng rel	ay fr	om		J10-25 J14-14
Y2	Same as above except for Y2 relay.	Same as above except for Y2 relay.							J10-24 J14-30			
¥3	Same as above except for Y3 relay.	X			8-0	d inte	Ante	1	-	3	3-1	J10-22 J14-29
¥4	Same as above except for Y4 relay.	2.0.1	in no	1	Die .		10	A Can	un Gett	1 2 Par	V B.W	J9-36 J14-32
¥5	Same as above except for Y5 relay.											J9-37 J14-33
				and a		-			TAN		INT	late proper

ISS 4, SECTION 518-450-100

TABLE AA

INPUTS AND OUTPUTS-424B/424C KTU

TEST FROM	то	MON/TALK SWITCH	TEST FOR	REMARKS
			INPUTS	
GROUND	J10-18	TALK	A Battery	
	J10-17		B Battery	
J18-17	J9-15	TALK	B Ground	
J18-18	J10-3	TALK	A Ground	
			OUTPUTS	
GROUND	VS lead	MON	1 sec. tone burst on VS lead of station tested. See Fig. 70 for VS lead assignment.	Tone burst heard after dialing proper digit(s)
	J10-19	TALK	Ground – BY1 lead	Dialing complete— 1- or 2-digit code
B BAT	J10-30		Ground — LK lead	After dialing 1st digit, dial tone should be removed
	J10-39		Ground - TTG lead	Selector seized
GROUND	J10-35		B BAT. – BR lead	Selector seized

TABLE AB

INPUTS AND OUTPUTS-440A OR 478B KTU

TEST FROM	то	MON/TALK SWITCH	TEST FOR	REMARKS
			INPUTS	
GROUND	J14-8	TALK	A Battery	112070
A BAT.	J13-3 J14-3	TALK	A Ground	Required for 478B KTU only
J14-12	J14-13	MON	Multifrequency signals	Either IC path seized – any dial button depressed
			OUTPUTS	
DDAT	J14-26	TALK	B Ground — LK lead	1st digit of 2-digit code dialed
B BAT.	J14-36	TALK	B Ground — TTG lead	Selector seized

TABLE AC

INPUTS AND OUTPUTS-456B KTU

TEST FROM	то	MON/TALK SWITCH	TEST FOR	REMARKS	
			INPUTS		
GROUND	J16-18		A Battery	State Constrained	
J16-18	J16-3		A Ground	SIL -IAA	
J16-8	J16-9	TALK	TALK	Talk Battery from 460B KTU – TC and RC leads	Any intercom path seized
J16-18	J16-19		Ground - from 424B/424C KTU (BY1 lead) after dialing is completed on any path	40432 10 10 10 10 10 10 10 10 10 10 10 10 10	
		1	OUTPUTS		
J16-8	J16-9	(mill)	Tone burst after dialing	Any code dialed — any path	
	J16-1	MON	Tone burst after dialing	Any code dialed — any path	
GROUND	J16-0		Voice conversation on intercom paging calls.	Dial 2 if paging is furnished – tone burst and voice should be heard	

Page 112

518,450,100,i04 1979,04-112 ipg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:10:11

TABLE AD

INPUTS AND OUTPUTS - 460B KTU

TEST FROM	то	MON/TALK SWITCH	TEST FOR	REMARKS
			INPUTS	
	J11-18		A BAT. — intercom talk battery	i F
	J11-17	TALK	B BAT. — intercom relay battery	
GROUND	J12-4	MON	10V± steady lamp voltage — paths 1 and 2	
	J12-35	TALK	B Battery	Selector seized
	J12-7	MON	10V± at 60 IPM — lamp flash	Interrupter running
	J11-3		A Ground	Let 1
J11-17	J11-15	TALK	B Ground	
	J11-6		Ground — MG lead	
			OUTPUTS	
J12-14	J12-34		Talk Battery — path 1	
J12-0	J12-1	TALK	Talk Battery – path 2	Selector seized
	J12-8	-	and the second s	
CROUND	J12-9	MON	10V+ at 60 IPM	Intercom path 1 seized
GROUND	J11-16	MON		Intercom nath 2 saized
	J11-19		- Minho	
J12-12	J12-13	TALK	Talk BAT TC and RC leads	Any path seized







SECTION 518-450-100

CONNECTING BLOCK KSU CONNECTOR 5 3 J9 J10 JII J12 1 J14 J16 IL2(0) 35H F14 × 16 IL2(3) 356 4 19 A ris IL2(4-11) 35B -< 35 (A-H) 35B (A-H) 35 IL2(12-18) - 14 YI 42E ~ 25 ≺ 30 Y2 43E 24 -0 - 29 ¥3 44E 22 -0-- 32 ¥4 45E ≺ 36 ≺ 33 ¥5 46E - 37 ٦. 38E LT2 ≺ 39 26E DO -0-- 16 € 27E DI - 16 FK 19 BYI - 19 **► 26** - 19 * I86A NETWORK RH ≺ 26

Fig. 70-Intercom Circuit (Sheet 2 of 4)

ISS 4, SECTION 518-450-100

Page 115

518-450-100-104_1979-04-115.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:11:01

518-450-100-i04 1979-04-116.ipg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:11:16

Page 116



Fig. 70-Intercom Circuit (Sheet 3 of 4)

SECTION 518-450-100

CONNECTING BLOCK KSU CONNECTOR J9 J10 J12 J15 J16 5 3 1 J14 VS12 42A IID -0 -0 × 22 42B VSI3 120 ~ 24 -0-420 VS14 13D - 27 -0-42D ¥\$15 14D -0--0-< 0 VS16 42E 150 -0-< 1 42F VSI7 16D -0--0-≺ 33 VS18 42G 170 - 31 -0--0 42H 18D VS19 -0-() 22A 0 0 0 (M) WITHOUT DSS T PRESET CONFERENCE 228 -0-W WITHOUT PRESET CONFERENCE 220 -0-13G 13F 13E < 9 IOF 106 14F 14E 17E 17F -0-0 22E 220 Fig. 70-Intercom Circuit (Sheet 4 of 4)

518-450-100-104_1979-04-117.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:11:33

Page 117

ISS 4, SECTION 518-450-100

TABLE AE

PAGING-457C KTU



518-450-100-i04 1979-04-118.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:11:47

TABLE AF

LEAD TABLE - 457C KTU

LEAD DESIG.	FUNCTION	KSU/CONNECTOR PIN NO. J15-16 J15-19	
PA	Paging input — voice and tone alerting input from the 456B KTU.		
PC	Paging code — when code 2 is dialed, -24V is applied to this lead from 456B KTU to enable amplifier.		
P0-P1	Paging amplifier output — outputs from paging amplifier to speakers.	J15-0 J15-1	

TABLE AG

INPUTS AND OUTPUTS - 457C KTU

TEST FROM	то	MON/TALK SWITCH	TEST FOR	REMARKS
			INPUTS	
CROUND	J15-18		A Battery	
GROUND	J15-17		B Battery	
J15-17	J15-15	TALK	B Ground	
GROUND	J15-19		A Battery (PC lead)	Code 2 dialed
J15-8	J15-9	MON	Background music	If provided
			OUTPUTS	
GROUND	J15-0	MON	Voice and taxa election	Code 2 dialed; voice input at calling station
	J15-1	MON	voice and tone alerting	

SECTION 518-450-100



Fig. 71-Paging Connections

TABLE AH

BACKGROUND MUSIC

Paging circuit idle.



-518-450-100-i04_1979-04-121.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:12:38

TABLE AI

MUSIC ON HOLD

Call in progress on CO/PBX line.

Hold button depressed at 7A station.

Line button restores; lamp flashes. Background music heard by held party.

OK

(a) Line circuit troublesrefer to sequence on line circuits

FAILURE

- (b) No background music
 1. COAM music source defective, wrong
- connections, or improperly set volume.
- 2. Defective 33A coupler or fuses operated.
- Open MT and/or MR lead— 33A, 451B, 498A.
- 4. Open R(CO) or R(STA).
- 5. Open L or A lead (498A).

Line button depressed.

FAILURE 1. Defective tel set.

2. Defective line circuit.

OK

Background music removed; voice conversation reestablished.

TABLE AJ

LEAD TABLE-451-TYPE KTU

LEAD DESIG	FUNCTION	KSU/CONNECTOR PIN NO.
МТ	Music tip — tip side of music source input — through 33A voice coupler	J18-35
MR	Music ring — ring side of music source input — through 33A voice coupler	J18-36
R (CO)	Ring (Central Office) — multiple of ring side of CO/PBX circuit	J18-19, 39, 24, 14, 31, 34, 28
R (STA)	Ring (Station) — multiple of ring side of line toward station	J18-20, 30, 25, 9, 16, 32, 29

TABLE AK

INPUTS AND OUTPUTS-451-TYPE KTU

TEST FROM	то	MON/TALK SWITCH	TEST FOR	REMARKS
			INPUTS	half and a second
J18-35	J18-36	MON	Music-on-hold output	Music source connected
		11	OUTPUTS	
J18-19	J18-20		Music-on-hold output	CO/PBX line 1 on hold
J18-39	J18-30		Music-on-hold output	CO/PBX line 2 on hold
J18-24	J18-25		Music-on-hold output	CO/PBX line 3 on hold
J18-14	J18-9	MON	Music-on-hold output	CO/PBX line 4 on hold
J18-31	J18-16		Music-on-hold output	CO/PBX line 5 on hold
J18-34	J18-32		Music-on-hold output	CO/PBX line 6 on hold
J18-28	J18-29		Music-on-hold output	CO/PBX line 7 on hold



TABLE AL

LEAD DESIG	FUNCTION	KSU/CONNECTOR PIN NO.
MT	Music tip — tip side of music source input — through 33A voice coupler	J18-12
MR	Music ring — ring side of music source input — through 33A voice coupler	J18-38
R (STA)	Ring (Station) — multiple of ring side of line toward station	J18-37, 19, 39, 16, 30, 31, 32
T (STA)	Tip (Station) — multiple of tip side of line toward station	J18-34, 36, 35, 14, 11, 13, 33
L	Lamp — multiple of lamp lead toward station	J18-0, 24, 23, 20, 28, 27, 29
A	A lead — multiple of A lead toward station	J18-21, 25, 22, 1, 8, 9, 26

LEAD TABLE - 498A KTU EQUIPPED WITH 116A1CM

TABLE AM

INPUTS AND OUTPUTS - 498A KTU

TEST FROM	то	MON/TALK SWITCH	TEST FOR	REMARKS
		Ener	INPUTS	ale ale
J18-12	J18-38	MON	Music-on-hold input	Music source connected
			OUTPUTS	
J18-34	J18-37	F.11	Music-on-hold output	CO/PBX line 1 on hold
J18-36	J18-19		Music-on-hold output	CO/PBX line 2 on hold
J18-35	J18-39		Music-on-hold output	CO/PBX line 3 on hold
J18-14	J18-16	MON	Music-on-hold output	CO/PBX line 4 on hold
J18-11	J18-30		Music-on-hold output	CO/PBX line 5 on hold
J18-13	J18-31		Music-on-hold output	CO/PBX line 6 on hold
J18-33	J18-32		Music-on-hold output	CO/PBX line 7 on hold

	CONN PLOCK 2	CONN BLOCK 2	FUSE		CONNECTOR
TO 334 / MT	DLUCK S	DLUCK 2	PANEL		510
VOICE MP					< 12
COUPLER L TI		12A, 9A 9B		CONNECTOR J1	< 38
R1	26	12B 12D .9D		12	< 34
11		0 0 0 0	F1	13	(37
14	46		2~1	8	0
_12.				16>	(21
TO	50	126 12F 9F		CONNECTOR J2	
			11	12	36
- 10			F2	13	(19
12			201	8	24
_A2				16	25
		164 124 120		0000000000000	-
_13				LUNNECTUR J3	1 25
			E2	12	29
				13	39
			E 1	16	20
				0000000000	-
		166 16E 13E		CUNNECTUR J4	
R4		16H 13H 13G		12>	14
_L4				13>	16
			2 1	8>	20
				16>	1
	17G	20A 17A 17B		CONNECTOR J5	
R5	186	20B 20D 17D		12>	11
_L5	196		F5	13>	< 30
_A5	206	1000 Let 1	2 1	8>	< 28
				16>	<8
TG	216	20G 20E , 17E		CONNECTOR J6	1
R6	226	20H , 17H 17G		12>	< 13
1.6	236		F6	13>	< 31
AG	246		2~1	8>	27
			1	16>	< 9
17	256	24A, 21A 21B		CONNECTOR J7	-
	260	24B 24D ,21D		12)	< 33
17	276	0000	F7	13>	< 32
A7	286		2~1	8>	< 29
				16>	26
				,	

Fig. 73-Music-On-Hold (570B KSU)

ISS 4, SECTION 518-450-100



Fig. 74-Power Distribution (Sheet 1 of 6)



C. -24V B BATTERY





Fig. 74-Power Distribution (Sheet 3 of 6)



ISS 4, SECTION 518-450-100



H. LAMP GROUND







J. MISCELLANEOUS GROUNDS

Fig. 74-Power Distribution (Sheet 5 of 6)

Page 131/132

ISS 4, SECTION 518-450-100



L. MOTOR START (MS) LEAD

Fig. 74-Power Distribution (Sheet 6 of 6)



Fig. 75-Condensed Functional Schematic of 400G KTU (CO/PBX Line Circuits) (Sheet 1 of 2)

Page 134

518-450-100-i04_1979-04-133.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:16:01







0 - OPERATED

Fig. 76-Condensed Functional Schematic of 400H KTU (CO/PBX Line Circuit) (Sheet 1 of 2)

ISS 4, SECTION 518-450-100



Fig. 76-Condensed Functional Schematic of 400H KTU (CO/PBX Line Circuit) (Sheet 2 of 2)





Fig. 77-Condensed Functional Schematic of 424C KTU (Dial Intercom 19-Code Selector Circuit)

518-450-100-i04_1979-04-137.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:19:55



Fig. 78—Condensed Functional Schematic of 440A KTU (MD) (TOUCH-TONE Adapter Circuit)

ISS 4, SECTION 518-450-100

518-450-100-i04_1979-04-138.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:20:26









Fig. 81—Condensed Functional Schematic of 455A KTU (Tone-Ringing Signal Generator Circuit)

second unternet and the second of the state of the strength in the state of the state of the





KTU (

518-450-100-104_1979-04-142.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:21:44



and burner many to the second s



Fig. 84—Condensed Functional Schematic of 460B KTU (2-Path Intercom Access Circuit) (Sheet 1 of 2)


Fig. 84—Condensed Functional Schematic of 460B KTU (2-Path Intercom Access Circuit) (Sheet 2 of 2)

Page 148



SECTION 518-450-100

518-450-100-i04_1979-04-146.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:22:54



Fig. 86-Condensed Functional Schematic of 498A KTU (Music-On-Hold Circuit)

ISS 4, SECTION 518-450-100



Fig. 87-6A1 Station Busy Console With DSS, Schematic (Sheet 1 of



Page 151

18-450-100-i04_1979-04-149.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:23:46



TO CONN BLOCK 3





Page 153 153 Pages

18-450-100-i04_1979-04-151.jpg Scanned by Frank Harrell (Cowboy Frank) Castle Rock, Colorado 6/11/2017 / 22:24:18